

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B-11478

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name State "Y"
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>25</u> TOWNSHIP <u>25-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wilocat Langlie Mattix
15. Elevation (Show whether DF, RT, GR, etc.) 3075' RKB	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is no longer capable of producing gas in commercial quantities and no remedial prospects exist. We propose to P & A as outlined below.

1. Set 30 sx neat cement from 2840-2980'.
2. Set 10 sx neat cement in top of well.

Leave 9#/gal salt gel mud between plugs. 9-5/8" and 7" casing strings were cemented to surface and will remain intact. Dry hole marker will be erected and location cleared and levelled.

If no pipe is pulled, perforate @ 1000' & squeeze 50 sx's. thru perms

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>P.D. Litcher</u>	TITLE <u>Dist. Drlg. Supervisor</u>	DATE <u>3/13/72</u>
APPROVED BY <u>Joe D. Ramsey</u> Dist. I, Supv.	TITLE _____	DATE <u>MAR 15 1972</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

MAR 14 1972

OIL CONSERVATION COMM.
HOBBS, N. M.