

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
NM 13010	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator American Exploration Company	8. Farm or Lease Name Alston
3. Address of Operator 2100 RepublicBank Center, Houston, Texas 77002	9. Well No. 2
4. Location of Well UNIT LETTER <u>E</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>26</u> TOWNSHIP <u>25S</u> RANGE <u>37E</u> N.M.P.M.	10. Field and Pool, or Whelan Langlie Mattix SR-Q
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

American Exploration Company proposes to plug and abandon the subject as follows:

RU SWU. Set CIBP 50' above casing shoe. Cap with 50' cement. Cust casing at 1300'. Circulate mud as required by state. Watch for gas while circulating. Pull casing. Spot 150' plug across casing stub (75' in / 75' out). Set 150' plug across 10-3/4" shoe (75' below / 75' above). Cut casing off 4' below ground level. Spot 20' plug at surface. Weld cap on casing with required information attached. Clean location.

RECEIVED  
OCT 10 1988  
OIL CONSERVATION DIVISION  
SANTA FE, NEW MEXICO

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNED <u>Marty McClellan</u>	TITLE <u>Production Dept.</u>
DATE <u>9/14/88</u>	
APPROVED BY <u>JERRY SEXTON</u>	TITLE <u>DISTRICT I SUPERVISOR</u>
DATE <u>SEP 19 1988</u>	
CONDITIONS OF APPROVAL, IF ANY:	

RECEIVED

SEP 16 1988

OCD  
HOBBS OFFICE