

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
West Dollarhide Queen Sand Unit	
8. Farm or Lease Name	
West Dollarhide Queen Sand Unit	
9. Well No.	
10	
10. Field and Pool, or Wildcat	
Dollarhide Queen	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator
	Skelly Oil Company
3. Address of Operator	
P. O. Box 1351, Midland, Texas 79701	
4. Location of Well	
UNIT LETTER <u>F</u> , <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>West</u> LINE, SECTION <u>30</u> TOWNSHIP <u>24S</u> RANGE <u>38E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	
3135' KB	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has not responded to waterflood operations. In order to reduce operating expenses we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull rods, tubing and packer.
- 2) Set 5-1/2" bridge plug at 3630'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 1000-1770' across top of salt section.
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

20 hr. notice

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>J. R. Avent</u>	TITLE <u>Dist. Admin. Coordinator</u>	DATE <u>March 4, 1973</u>
Orig. Signed by <u>Joe M. Ramey</u>		
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		