

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT
(Other 1.
verse side)

RIPLICATE
tions on re

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

LC-067968 069052

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

West Dollardhide Queen Sand Unit

8. FARM OR LEASE NAME

West Dollardhide Queen Sand Unit

9. WELL NO.

31

10. FIELD AND POOL, OR WILDCAT

Dollardhide Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 31-24S-38E

12. COUNTY OR PARISH

Lee

New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

1139' KB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well is uneconomical to operate and in order to reduce operating expense, we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull production equipment.
- 2) Set 5-1/2" bridge plug at approximately 3540' and cap with 25 sacks of cement.
- 3) Spot 100 sack cement plug across the top of salt section approximately 950-1720'.
- 4) Spot 10 sack cement plug at the surface.
- 5) Install dry hole marker.

All intervals not cemented will be filled with 10.2# mud. No casing will be pulled.

The 10-3/4" OD casing set at 206', and 7" OD casing set at 3560' will be left in the hole.

AMENDMENT: 1. Place additional 25 sack plug inside 5 1/4" casing in interval 2600-2800 feet.

2. If no 5 1/4" casing is pulled, perforate at 1300 feet and place sufficient cement to have 200 feet of cement outside casing in interval 1100-1300 feet and a 200 foot plug inside 5 1/4" casing in this same interval.

18. I hereby certify that the foregoing is true and correct

SIGNED J. R. Avent

TITLE Dist. Admin. Coordinator

DATE 1-7-74

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.