

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> <b>Water Injection Well</b>	7. Unit Agreement Name <b>West Dollarhide Queen Sand Unit</b>
2. Name of Operator <b>Skelly Oil Company</b>	8. Farm or Lease Name <b>West Dollarhide Queen Sand Unit</b>
3. Address of Operator <b>P. O. Box 1351, Midland, Texas 79701</b>	9. Well No. <b>42</b>
4. Location of Well UNIT LETTER <b>P</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>990</b> FEET FROM THE <b>East</b> LINE, SECTION <b>32</b> TOWNSHIP <b>24S</b> RANGE <b>38E</b> N.M.P.M.	10. Field and Pool, or Wildcat <b>Dollarhide Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3173' DF</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**This well is in an area that has not responded to waterflood operations. In order to reduce operating expenses, we propose to plug and abandon the well as follows:**

- 1) Move in pulling unit. Pull tubing and packer.
- 2) Set 5-1/2" bridge plug at 3650'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks 950-1720' across top of salt section.
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

**All intervals not cemented will be filled with 10.2# mud.**

*24 hr. no time*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **J. E. Avent J. R. Avent**

TITLE **Dist. Admin. Coordinator**

DATE **March 4, 1973**

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: