

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B-9613

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	West Dollarhide Queen Sand Unit
Skelly Oil Company	8. Farm or Lease Name
3. Address of Operator	West Dollarhide Queen Sand Unit
P. O. Box 1351, Midland, Texas 79701	9. Well No.
4. Location of Well	29
UNIT LETTER F 2310 FEET FROM THE North LINE AND 1650 FEET FROM	10. Field and Pool, or Wildcat
THE West LINE, SECTION 32 TOWNSHIP 24S RANGE 38E NMPM.	Dollarhide Queen
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3183' DF	Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has not responded to waterflood operations. In order to reduce operating expenses we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull rods, tubing and packer.
- 2) Set 5-1/2" bridge plug at 3580'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 1000-1770' across top of salt section.
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

24 hr no file

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED	TITLE	DATE
J. R. Avent	Dist. Admin. Coordinator	March 4, 1973
Or: Signed by		
Joe D. Ramey		
Dist. I, Supv.		
APPROVED BY	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		