

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE **APPLICATION FOR PERMIT -** (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection Well</b>	5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator <b>Skelly Oil Company</b>	5. State Oil & Gas Lease No.
3. Address of Operator <b>P. O. Box 1351, Midland, Texas 79701</b>	7. Unit Agreement Name <b>West Dollarhide Queen Sand Unit</b>
4. Location of Well UNIT LETTER <b>G</b> , <b>2310</b> FEET FROM THE <b>North</b> LINE AND <b>2260</b> FEET FROM THE <b>East</b> LINE, SECTION <b>32</b> TOWNSHIP <b>24S</b> RANGE <b>38E</b> NMPM.	8. Farm or Lease Name <b>West Dollarhide Queen Sand Unit</b>
	9. Well No. <b>28</b>
	10. Field and Pool, or Wildcat <b>Dollarhide Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3225' KB</b>	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is in an area that has not responded to water flood operations. In order to reduce operating expenses we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull tubing and packer.
- 2) Set 5-1/2" bridge plug at 3650'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 1000-1770' across top of salt section.
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

*24 hr. notice*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
SIGNED	<b>J. R. Avent</b>	TITLE	<b>Dist. Admin. Coordinator</b>
		DATE	<b>March 4, 1973</b>
APPROVED BY	<b>Joe D. Ramey</b> Dist. I. Supv.	TITLE	
CONDITIONS OF APPROVAL, IF ANY:			