

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.O.S.		
LAND OFFICE		
OPERATOR		

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease

State ☒ Fee ☐

5. State Oil & Gas Lease No.

E-0789-1

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well	7. Unit Agreement Name
2. Name of Operator Tenneco Oil Company	8. Farm or Lease Name Monsanto State
3. Address of Operator 7990 IH 10 West; San Antonio, Texas 78230	9. Well No. 7
4. Location of Well UNIT LETTER M 330 FEET FROM THE South LINE AND 990 FEET FROM West LINE, SECTION 16 TOWNSHIP 25S RANGE 32E NMPM.	10. Field and Pool, or Wildcat Paduca Delaware
15. Elevation (Show whether DF, RT, GR, etc.) 3401' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MIRU PU. ND wellhead. NUBOP. RIH with approximately 160 joints 2-3/8 8rd J55 tubing and tag bottom. Circulate out any fill. (TD: 4700'). POOH with tubing.
- Swab well. Depending on results:
 - RIH with 153 joints 2-3/8 8rd J55 tubing, and seating nipple to \pm 4600'. NDBOP. RIH with rods and pump. Set pumping unit. Put on production.
 - OR
 - RIH with 2-3/8" tubing and CIBP. Set CIBP at \pm 4500'. POOH with tubing. NDBOP. NU wellhead.
- Return well to injection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Division Production Manager DATE 10-12-83

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____ DATE OCT 20 1983

RECEIVED

OCT 19 1983

GOVERNMENT
HOBBY-LOVE