Form 3 160-5 (June 1990)	UNITED S DEPARTMENT OF BUREAU OF LAND	THE INTERIOR	FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 3 1 ,1993 5. Lease Designation and Seriai No.
Do not use this f	SUNDRY NOTICES AND orm for proposals to drill or to Use "APPLICATION FOR PE	REPORTS ON WELLS	NM 0321613 6. If Indian, Allonee or Tribe Name
1. Type of Well	SUBMIT IN T	RIPLICA TE	7. If Unit or CA, Agreement Designation
2. Name of Operator	8. Well Name and No. Jack B-26 No.2 9. API Well No.		
<ol> <li>Address and Telephone 1</li> <li>10 DESTA DR.</li> <li>4. Location of Well (Foot</li> </ol>	30-025-21065 10. Field and Pool, or Exploratory Area		
	Justis Tubb Drinkard 35280 11. County or Parish, State		
tn CHECK	APPROPRIATE BOX(s) TO	INDICATE NATURE OF NOTICE,	
TYPE OF	SUBMISSION	ACTION	
	of Intent lent Repon pandonment Notice	Abandonment Recompletion Plugging Back Casing Repair Altering Casing Other <u>Casing Integrity</u>	Change of Plans Change of Plans Construction Non-Routine Fracrunng Water Shut-Off Conversion to Injection Test INole: Reponresuitsof multiplecompitiononWdl

13 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is proposed to perform a casing integrity test on the well in preparation for requesting temporary abandonment approval. See attached procedure and reason.

When completed, a successful pressure test will be submitted with a reqson and a request to temporarily abandon this well for another year.

14. I hereby certify that the foregoing is true and corrict		Reesa R. Wilkes		<u> </u>
Signed THERE WINES	Title	Staff Regulatory Assistant	Date _	2-25-99
W (This space for Federal or State office use) Approved by (ORIG, SGD.) LES BABYAK Conditions of approval if any:		TOTI FUM ENGINEER	Date	MAR 2 9 1999

\*See Instruction on Reverse Side

らんい



÷

## JACK B-26 #2 RECOMMENDATION TO TEMP ABANDON

This well is currently inactive. It is recommended the well be temporarily abandoned in order to evaluate Ellenburger potential.

Prepare well bore as follows:

- 1. POH with existing pump, rods and tubing.
- 2. Make scraper run inside  $4.5^{\circ}$ ,  $9.5 10.5^{\circ}$  casing to top perf.
- 3. Set Cast Iron Bridge Plug within 50' of top perf, spot 35' of cement on top of CIBP.
- 4. Circulate casing with inhibited packer fluid.
- 5. Pressure test casing to 500# for 30 minutes. Give BLM 24 hrs notice prior to pressure test.