

UNITED STATES
DEPARTMENT OF THE INTERIORSUBMIT IN TRIPLICATE*
(Other instruction
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill, to open or plug back to a different reservoir.
Use APPLICATION FOR PERMIT TO DRILL for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> Well drilled as a dry gas well and salvage has been deferred until now.	6. IF INDIAN, ALLOTTEE OR TRIBE NAME None
2. NAME OF OPERATOR TEXACO Inc.	7. UNIT AGREEMENT NAME Cotton Draw Unit
3. ADDRESS OF OPERATOR P. O. Box 728, Hobbs, New Mexico 88240	8. FARM OR LEASE NAME Cotton Draw Unit
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface Well is located 760' from the West Line, and 2080' from the North Line of Section 10, T-25-S, R-32-E, Lea County, New Mexico.	9. WELL NO. 66
14. PERMIT NO. Regular	10. FIELD AND POOL, OR WILDCAT Undesignated Morrow Gas Wildcat
15. ELEVATIONS (Show whether DF, HT, GR, etc.) 3479' (D. F.)	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 10, T-25-S, R-32-E
	12. COUNTY OR PARISH Lea
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

TEXACO proposes to plug and abandon the following well as follows:

1. Load tubing and annulus with 10# brine.
2. Remove well head and pull tubing.
3. Install B. O. P.
4. Run Bridge Plug on wire line and set @ 12,450'.
5. Dump 5 cu. (20') cement on bridge plug w/ dump bailer.
6. Spot 15 cu. (30') cement at surface.
7. Set marker, clean up location.
8. Plug and abandon complete on or about July 31, 1968.

STEP 5 AS AMENDED:

Spot 200' cement plug on top of bridge plug and fill hole with a quality mud.

18. I hereby certify that the foregoing is true and correct

SIGNED

(This space for Federal or State office use)

TITLE

Assistant District
Superintendent

DATE

July 17, 1968

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side