

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator HNG Oil Company		8. Farm or Lease Name Vance 30	
3. Address of Operator c/o Hobbs Pine & Supply Company, Box 2010, Hobbs, New Mexico		9. Well No. 2	
4. Location of Well UNIT LETTER <u>K</u> , <u>2,110</u> FEET FROM THE <u>West</u> LINE AND <u>1,650</u> FEET FROM THE <u>South</u> LINE, SECTION <u>30</u> TOWNSHIP <u>24</u> RANGE <u>38</u> NMPM.		10. Field and Pool, or Wildcat Dollarhide/Devonion	
15. Elevation (Show whether DF, RT, GR, etc.) 3,104' GR		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spot a 100' plug to cover all existing perforations.
2. Load hole w/mud-laden fluids.
3. Pull 5-1/2" casing from approx. 4,500' & spot a 100' stub plug.
4. Spot a 100' plug in and out of intermediate shoe at 3,830'.
5. Spot a 10 Sx top-hole plug and erect a 4" regulation marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Stanley Sackin TITLE AGENT DATE 10/30/73

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]  
CONDITIONS OF APPROVAL, IF ANY: