

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

Federal LC-067968

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

RAF 30

9. WELL NO.

4

10. FIELD AND POOL, OR WILDCAT

W ~~est~~ Dollarhide (Fuss)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

30-24-38

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

HNG OIL COMPANY

3. ADDRESS OF OPERATOR

P.O. Box 2267 - Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface:

1650' FSL & 330' FEL of Sec. 30, T-24-S, R-38-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3166 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

SUBSEQUENT REPORT OF:

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

(See attached plat for well casing detail)

1. Load hole w/mud.
2. Pull tbg and set 4-1/2" BP @ 7700' w/3 sx cmt on top.
3. Spot 25 sx. plug from 5680-6000'.
4. Locate free point of 4-1/2" csg. shoot or cut csg.
5. Spot 50 sx. cmt plug opposite cag part or cut.
6. Spot 30 sx. cmt plug just above Rustler in 7-5/8". (Rustler @ 1207')
7. Spot 10 sx. plug @ surface & install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

Chas. A. Lutz

TITLE Area Production Foreman DATE 1-12-77

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE