

10. COPIES RECEIVED		
DISTRIBUTION		
NTA FE		
E		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
NMF 539	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Texas Pacific Oil Company, Inc.		8. Farm or Lease Name Eaton, N.E.
3. Address of Operator P. O. Box 4067, Midland, Texas 79701		9. Well No. 18
4. Location of Well UNIT LETTER <u>B</u> <u>880</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>East</u> LINE, SECTION <u>12</u> TOWNSHIP <u>25-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat Justis
15. Elevation (Show whether DF, RT, GR, etc.) 3105.1' Gr.		12. County Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MIRUPU
- Set CIBP at 5350 inside 5½" Casing cap with 35' cement.
- Displace hole with mud to 1146'. Spot 100' cement across to p of salt section.
- Displace hole with mud - set 10 sacks cement at surface.
- Install dry hole marker & clean location.

NOTE: Commission will be called prior to setting CIBP.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED L. A. Wright TITLE Area Superintendent DATE July 25, 1975

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: