

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-1327	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Bravo Operating Co. 3. Address of Operator P. O. Box 2160 Hobbs, New Mexico 88240 4. Location of Well UNIT LETTER J, 1650 FEET FROM THE East LINE AND 2310 FEET FROM THE South LINE, SECTION 36 TOWNSHIP 25-S RANGE 36-E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) GL 2981' KB 2994'	7. Unit Agreement Name 8. Farm or Lease Name Eagle 9. Well No. 1 10. Field and Pool, or Wildcat Jalmat 12. County Lea
---	---

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull tubing and set CIBP @ 2700'± and cap with 3 sx cement.
2. Displace hole with salt gel mud. *20 lb gel mud*
3. Set 20 sx cement plug at 2700'±.
4. Set 20 sx cement plug at 1300'±.
5. Set 20 sx cement plug at surface.
6. Remove well head. Install dry hole marker. Cut off anchors.
7. Remove surface equipment and ready location for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe T. Juncos TITLE NRE, Agents for Bravo Operating DATE March 30, 1987
Orig. Signed by Paul Kautz
APPROVED BY Geologist TITLE DATE APR 7 1987
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
APR 16 1987
OCD
HOBBS OFFICE