

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
ALBUQUERQUE, NEW MEXICO 87105

SUBMIT IN TRIPLI
(Other instructions
verse side)

E*
re

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-069052

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection

2. NAME OF OPERATOR

Sirgo Operating, Inc.

3. ADDRESS OF OPERATOR

P.O. Box 3531, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

Unit C, 330 FNL 2360 FWL

7. UNIT AGREEMENT NAME

West Dollarhide Queen Sand Un.

8. FARM OR LEASE NAME

9. WELL NO.

113

10. FIELD AND POOL, OR WILDCAT

Dollarhide Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 31 T-24-S R-38-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3108' GR

12. COUNTY OR PARISH

Lea

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) Finish Completion & Prep to Inject

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU PU. Perf Lower Queen. Run packer in tubing and acidize. Flow & swab back acid.
2. Pull tubing and packer. Set RBP above Lower Queen.
3. Perf Upper Queen. Run packer on tubing and acidize. Flow and swab back acid.
4. Pull packer and RBP.
5. Run injection packer on plastic coated tubing. Set packer 100' above top perf. Test backside to 500 psi for 30 minutes.
6. Place well on injection.

Submittal to
LBR approval
by State

RECEIVED

MAY 12 12:01 PM '89

18. I hereby certify that the foregoing is true and correct

SIGNED

Bonnie C. Custer

TITLE Production Technician

DATE 5-11-89

(This space for Federal or State office use)

APPROVED BY

[Signature]

FOR:

DATE 5-23-89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side