

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-09695
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Lease Name or Unit Agreement Name Everett
2. Name of Operator Convest Energy Corporation	8. Well No. 2
3. Address of Operator 2401 Fountain View Dr., Suite 700, Houston, TX 77057	9. Pool name or Wildcat Jalmat T-Y-SR
4. Well Location Unit Letter <u>N</u> : <u>660</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>35</u> Township <u>24S</u> Range <u>36E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 3100'+.
2. Spot cement plug #1 from 3100' to 3065'.
3. Cut & pull 7" casing at 1489'+.
4. Spot cement plug #2 from 1539' to 1439'.
5. Tag cement plug #2.
6. Spot cement plug #3 from 50' to surface.
7. Cut off & weld on marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE CAUS TO BE ALLOWED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Cheryl W. Daniels TITLE Engineering Technician DATE 9-9-94
TYPE OR PRINT NAME Cheryl W. Daniels TELEPHONE NO. _____

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE SEP 13 1994
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 12 1994

LIBRARY
OFFICE

EVERETT #2

12 1/2" 50# CSA 146' w/ 85 sk.

9 5/8" 40# CSA 1489' w/ 800 sk.

PERFS 3160' - 3400'

7" 24# CSA 3415' w/ 150 sk

OPEN HOLE FROM 3415' - 3492'

RECEIVED

SEP 12 1994

SEP 12 1994