

Form 3160-5  
(June 1990)

RECEIVED

JUL 27 10 40 AM '92

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.

NML CO 32618 A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

I.B. Oggs A #2

9. API Well No.

30025097010051

10. Field and Pool, or Exploratory Area

JALMAT T-Y-SR

11. County or Parish, State

LEA COUNTY  
NEW MEXICO

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

CONVEST ENERGY CORPORATION

3. Address and Telephone No.

2401 FOUNTAINVIEW SUITE 700, HOUSTON, TX 77057

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

600' FNL & 1980' FEL, Sec. 35, T24S-R36E  
660 Unit B

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

- 1) Notify BLM, Prior to any work @ (505) 393-3612
- 2) MI & RU Rig. Pool w/ Production eqt. LD. All except tubing.
- 3) GIH & Set. CIBP @ 3270' Spot 35' Cement on top of BP. w/ balw.
- 4) Displace hole w/ 9.0 #/gal. Mud.
- 5) Perf. @ 1725' and spot 100' Cement plug in + outside of 7" csg. TAG PLUG.
- 6) Perf. 9 5/8" csg @ 219' Set 100' Cement plug in + outside 9 5/8" csg. TAG PLUG.
- 7) Cut off csgs. 4' below ground level. Weld on PLATE + MARKER.
- 8) Level & RESTORE LOCATION.

14. I hereby certify that the foregoing is true and correct

Signed

*Ed Chamberlain*

Title

Agent

Date

7/20/92

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date

8/10/92