
Pal Pal CAT NEW 1 .30 OIL CONSERVATION COMP

Santa Fe, New Mexico



NOTICE OF INTENTION TO DRILL

OIL CONS			Midland,	Texas	March	8, 1950
	ERVATION	COMMISSION,	Pla	ce		Date
	New Mexico,	•				
Gentlemen:						
Yo	ou are hereby	notified that it is	our intention to con	nmence the drilli	ng of a well to be kn	NWN 98
CHTDO	* A.M. C. 77			TANKA		NE SW/4
of Sec. 24	, n	218 215	Tan'	47 4 4 4 4 4 4 4 4		
	N	, R	, N. M., P. M., . 2310		Field, Lea	County
	1 1 1	The Well	is feet	(N.) (8.7 of	the south line a	nd 2310 fee
		• 4	of the West		ection 24	
	+++	directions.) location from secti	on or other leg	al subdivision lines.	Cross out wrong
	- - - - - - - - - - 	If state la	nd the oil and gas le	ease is No	Assignment	Ma
	1-1-1-	If patente	d land the owner is	Ad	a Thomas	110
	•	Address .				
		If governm	nent land the permit	tee is		
		Address _				
		The lessee	is			
AREA	640 ACRES	Address .				
OCATE WE	LL CORRECT	Rotary to	e to drill well with d total depth	rilling equipmen	t as follows:	
he status	of a bond f				eneral Rules and Re	
ommission i	is as follows:	Culber	tson & Irwin	. Inc. bla	ineral Rules and Re	gulations of the
			casing and to land			
Size of	Size of		New or			
	Casing	Weight Per Foot	Second Hand	Depth	Landed or Cemented	Sacks Cement
Hole	·					
Hole	8-5/8"	28∦	S.H.	250	Cemented	to surfec
Hole		28#	S.H.	250	Cemented	l to surfac
Hele	8-5/8" 5½"	28# 14#	S.H. New	250 3000	Cemented Cemented	to surfac
Holo L] n	5½"	14#	New	3000	Cemented	*
Hole II # 8# changes in	5½" the above p	14# lan become advisab	New	3000	Comented	*
Hole 8# changes in at the first idditional in	52" the above p productive oi formation:	14# lan become advisab l or gas sand should	New le we will notify you loccur at a depth of will be demonstrated.	3000 The before cement about 3100	ting or landing casin	* ag. We estimate
Hole 8" changes in at the first idditional in and 200	the above p productive of formation:	lan become advisable or gas sand should *Oil string ough 2-stage	New le we will notify you come at a depth of will be come tool set at	3000 The before cement about 3100	ting or landing casin	* ng. We estimate Shoe
Hole 8" changes in at the first idditional in and 200	the above p productive of formation:	14# lan become advisab l or gas sand should	New le we will notify you come at a depth of will be come tool set at	3000 The before cement about 3100	ting or landing casin	* ng. We estimate
Hole 8" changes in at the first idditional in and 200	the above p productive of formation:	lan become advisable or gas sand should *Oil string ough 2-stage	New le we will notify you loccur at a depth of will be come tool set at a salt.	3000 The before cement of about 3100 Southed with approximate approximates	ting or landing casin	* ng. We estimate Shoe
the Hele 8" changes in at the first diditional in and 200 anhydri	the above p productive of formation: sax three secti	lan become advisable or gas sand should *Oil string ough 2-stage	New le we will notify you loccur at a depth of will be come tool set at a salt.	3000 The before cement of about 3100 The about 3100 The approximate approximate approximately yours,	cemented ting or landing casin feet. 200 sax at nately 1200	* shoe opposite
the Hele 8" changes in at the first diditional in and 200 anhydri	the above p productive of formation: SAX three sections in the section i	lan become advisable or gas sand should *Oil string ough 2-stage	New le we will notify you loccur at a depth of will be come tool set at a salt.	3000 The before cement about 3106 The about 3106 The approximally yours, Culbertso	cemented ting or landing casin feet. 200 sax at lately 1200	* ng. We estimate Shoe
the Hele 8" changes in at the first diditional in and 200 anhydri	the above p productive of formation: SAX three sections in the section i	lan become advisable or gas sand should *Oil string ough 2-stage	New le we will notify you loccur at a depth of will be come tool set at a salt.	3000 The before cement about 3106 The about 3106 The approximally yours, Culbertso	cemented ting or landing casin feet. 200 sax at nately 1200	* shoe opposite
the Hele 8" changes in at the first diditional in and 200 anhydri	the above p productive of formation: SAX three sections in the section i	lan become advisable or gas sand should *Oil string ough 2-stage	New le we will notify you occur at a depth of will be come tool set at a salt. 19 Sincere	3000 The before cement about 3106 The about 3106 The approximately yours, Culbertso	comented ting or landing casin feet. 200 sax at nately 1200	* shoe opposite
changes in at the first iditional in and 200 nhydri	the above p productive of formation: sax three sections is follows:	lan become advisable or gas sand should *Oil string ough 2-stage	New le we will notify you loccur at a depth of will be come tool set at salt. 19 Sincered By Position	3000 The before cement about 3106 The about 3106 The approximately yours, Culbertso Pres	cemented ting or landing casin feet. 200 sax at lately 1200	* shoe opposite