

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator McCulloch Oil Corporation		5. State Oil & Gas Lease No.
3. Address of Operator 2000 Classen Center, Suite 614-East, Okla. City, Okla. 73106		7. Unit Agreement Name
4. Location of Well UNIT LETTER M 554 FEET FROM THE South LINE AND 554 FEET FROM THE West LINE, SECTION 11 TOWNSHIP 24-S RANGE 37-E NMPM.		8. Farm or Lease Name Hair
15. Elevation (Show whether DF, RT, GR, etc.) 3223' GL; 3234' KB		9. Well No. 1
		10. Field and Pool, or Wildcat Fowler (Upper Yeso)
		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Upon securing the approval of the Commission, the following described plugging operation will commence:

1. Load hole with 9.5 ppg mud.
2. Set a CIBP at 5300' and cap it with 50' cement.
3. Cut off 5 1/2" casing at 4950' and pull. Spot 100' cement plugs at 4150', 2450' and 1100' and a 50' cement plug at the surface.
4. Permanently mark well according to Commission requirements.
5. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Runyan TITLE District Manager DATE 4/5/76
Orig. Signed by
John Runyan
Geologist
APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: