

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Dalport - Hair
9. Well No. 1
10. Field and Pool, or Wildcat Fowler (Upper Yesso)
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. CIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator WESTERN EQUIPMENT COMPANY
3. Address of Operator Box 5457, Midland, Tx 79701
4. Location of Well UNIT LETTER L 554 FEET FROM THE West LINE AND 1874 FEET FROM THE South LINE, SECTION 11 TOWNSHIP 24-S RANGE 37-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3203 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set a cast iron bridge plug above the top perforation at 5469'.
35' cement on top of BP

2. Shoot off 5 1/2" production casing at 4150' and set a 25 sack cement plug into and over the stub end. Pull 4150' of 5 1/2" casing.
100' plug @ ~~top~~ base seat

3. Set a 25 sack cement plug over the casing seat of the 8-5/8" surface string.

4. Set a 10 sack cement plug at the surface & install a dry hole marker.

5. Fill the pits and clean up the location for final inspection.
All plugs 100' in length
Mud 25 sacks Gel/100 bbls w tr.
24 hr. notice prior to setting plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>[Signature]</i>	TITLE Owner	DATE 26 Sep 72
APPROVED BY	Orig. Signed by Joe D. Ramsey Dist. I, Supv.	DATE SEP 28 1972
CONDITIONS OF APPROVAL, IF ANY:		