- a) 1500 gals gel pad b) 500 gals gel + 1 ppg 20/40 RC sand c) 500 gals gel + 2 ppg 20/40 RC sand d) 500 gals gel + 3 ppg 20/40 RC sand e) 1000 gals gel + 4 ppg 20/40 RC sand
- f) flush to top perf SWI to allow resin to cure.
- 27. Make couple of swab runs.
- 28. Release pkr. Drop down and catch RBP. TOH w/ RBP, pkr, & tbg. TIH w/ pumping equipment. Place well on production from all perfs 6840-7991'.