

- D. Pump 2000 gals gelled 2% KCL prepad and 15 - 7/8" RCNBS evenly spaced thru-out.
 - E. Pump 1000 gals gelled 2% pre-pad.
 - F. Pump 5000 gals Versagel 1500.
 - G. Pump 4000 gals 15% NEHCL
 - H. Flush w/5000 gals gelled 2% KCL.
- 7. Swab back load immediately. Eval fluid content and rate.
 - 8. Rlse pkr, lwr thru perfs, check PBTD. POH & LD WS.
 - 9. RIH w/2-3/8" & 2-7/8" tbg, 76 rod string, and 1¼" pump. TAC 7556
SN 7681 PN 7682 MA 7686 TS 7715.

RECEIVED

JUN 7 1983

D.C.D.
HOSES OFFICE