

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

**RECEIVED**  
 NEW MEXICO OIL CONSERVATION COMMISSION  
**AUG 5 - 1969**  
**O. C. C.**  
**ARTESIA, OFFICE**

Form C-103  
 Supersedes Old  
 C-102 and C-103  
 Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name	
Tracy	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Wildcat	
12. County	
Eddy	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Wildcat</b>
2. Name of Operator <b>Union Oil Company of California</b> ✓
3. Address of Operator <b>P. O. Box 671, Midland, Texas 79701</b>
4. Location of Well UNIT LETTER <b>C</b> , <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>10</b> TOWNSHIP <b>22-S</b> RANGE <b>27-E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>3124.5 GR</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	Testing <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

6-30-69 Set cast iron bridge plug at 10,200' and dumped 20' of cement on top of plug. Perf Wolfcamp with 2 shots per foot at 9845', 9823', 9809' and 9786'. Swabbed tubing dry and acidized 9786' to 9845' with 6000 gal. reg. 15% acid. Swabbed tubing dry. Perforated Wolfcamp with 2 shots per foot at 9745', 9743', 9713', 9673', 9647', 9575', 9573', 9569', and 9567' and acidized 9567' to 9845' with 6000 gal. XF acid. Swabbed load water. Shut well in 20 days and then loaded hole with brine water. Set cast iron bridge plug at 9500' and dumped 20' of cement on top of plug. Set cast iron bridge plug at 3550' and cut 3 slots with abrasijet tool at 3417', 3420', and 3424'. Acidized slots 3417' to 3424' with 500 gal mud acid followed by 500 gal 3% acid and then swabbed acid water with trace of oil. Sand fraced 3417' to 3424' with 2500# 20-40 mesh sand and swabbed load oil and frac oil. Well started flowing.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>J. R. Gray</u>	TITLE <u>Drilling Superintendent</u>	DATE <u>8-4-69</u>
APPROVED BY <u>W. A. Gressett</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>AUG 7 - 1969</u>

CONDITIONS OF APPROVAL, IF ANY: