

Form 3160-5
(March 2012)UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENTFORM APPROVED
OMB No. 1004-0137
Expires: October 31, 2014**SUNDRY NOTICES AND REPORTS ON WELLS**
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.5. Lease Serial No.
NM0272711

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE – Other instructions on page 2.

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

E. G. L. RESOURCES, INC.

3a. Address

PO BOX 10886, Midland, TX 79702

3b. Phone No. (include area code)

432-687-6560

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1,650' FSL & 1,650' FEL, SEC. 1, TWP. 23-S, RGE. 24-E

7. If Unit of CA/Agreement, Name and/or No.
ROCK TANK UNIT

8. Well Name and No.

4

9. API Well No.

30-015-20320

10. Field and Pool or Exploratory Area
ROCK TANK - UPPER MORROW

11. County or Parish, State

EDDY COUNTY, NEW MEXICO

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other _____
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

SUMMARY OF PROPOSED OPERATIONS:

1. MIRU. ND wellhead. NU BOPE.
2. Set 850' cement plug from 9,815' to 8,965' with 120 sxs Class "H" cement. Pull above cement.
3. Circulate wellbore with 9 ppg mud.
4. Set 276' cement plug from 8,560' to 8,284' with 45 sxs Class "H" cement. WOC & tag. Call BLM Carlsbad Office to witness tag.
5. Set 150' cement plug from 5,575' to 5,425' with 25 sxs Class "H" cement. Pull up to 2,550'.
6. Set 200' cement plug from 2,550' to 2,350' with 30 sxs Class "H" cement. WOC & tag. Call BLM Carlsbad Office to witness tag.
7. Set 60' cement plug from 60' to surface with 10 sxs Class "H" cement. POOH w/ tubing. ND BOPE. Wash up equipment.
8. Dig out cellar. Cut off casing strings at base of cellar. Install P&A marker as designated by BLM officer. Fill in cellar.
9. Clean location and move off location.

RECLAMATION PROCEDURE
ATTACHED

ATTACHMENTS:

- A. DETAILED PROCEDURE OF PROPOSED OPERATIONS
- B. WELLBORE DIAGRAM OF WELLBORE CURRENT STATUS
- C. WELLBORE DIAGRAM OF PROPOSED PLUGGED AND ABANDONED STATUS

RECEIVED ATTACHED FOR
APR 30 2013 CONDITIONS OF APPROVAL
NMOCD ARTESIA (See Changes)

14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed)

JOHN A. LANGHOFF

Title PETROLEUM ENGINEER

Signature

Date 11/30/2012

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

SEPS

Date

4-29-13

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

CFO

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

ROCK TANK UNIT NO. 4
1,650' FSL & 1,650' FEL, SEC 1, TWP 23S, RGE 24E
EDDY COUNTY, NEW MEXICO

PLUG AND ABANDONMENT PROPOSED PROCEDURE:

1. MIRU. ND wellhead. NUBOPE. RIH picking up additional 2-3/8" tubing to tag CICR at 9,815'. Mix and pump 120 sxs Class "H" neat cement (16.4 ppg) to spot 850' balanced plug on top of CICR at 9,815'. Pull above cement to 8,560'. Reverse circulate tubing clean.
2. Circulate wellbore with 9 ppg mud.
3. With tubing at 8,560', mix and pump 45 sxs Class "H" neat cement (16.4 ppg) to spot 276' balanced plug from 8,560' to 8,284'. Pull above cement to 7,500'. Reverse tubing clean. WOC. Call BLM Carlsbad Field Office representative at (575) 361-2822 to witness tag of cement plug.
4. Pull tubing up to 5,575'. Mix and pump 25 sxs Class "H" neat cement (16.4 ppg) to spot 150' balanced plug from 5,575' to 5,425'. Pull above cement to 5,100'. Reverse tubing clean.
5. NOTE: THIS PLUG WILL BE SET ACROSS SURFACE CASING SHOE. CEMENT BOND LOG DATED MAY 30, 2012 INDICATES GOOD CEMENT BETWEEN 5-1/2" CASING AND 8-5/8" SURFACE CASING. THEREFORE IT IS RECOMMENDED NOT TO PERF CASING AT SURFACE CASING SHOE. - Pull tubing up to 2,550'. Mix and pump 30 sxs Class "H" neat cement (16.4 ppg) to spot 200' balanced plug from 2,550' to 2,350'. Pull above cement to 2,100'. Reverse tubing clean. WOC. Call BLM Carlsbad Field Office representative at (575) 361-2822 to witness tag of cement plug.
6. Pull tubing up to 60'. Mix and pump 10 sxs Class "H" neat cement (16.4 ppg) to spot 60' balanced plug from 60' to surface circulating cement. Pull out of hole with tubing. ND BOPE. Wash up tubing and equipment.
7. Surface Cap. All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The well bore shall then be covered with a metal plate at least 1/4 inch thick and welded in place, or a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement as specified by the authorized officer. The well location and identity shall be permanently inscribed. A weep hole shall be left if a metal plate is welded in place.
8. The cellar shall be filled with suitable material as specified by the authorized officer and the surface restored in accordance with the instructions of the authorized officer.

WELL DATA SHEET

FIELD: Rock Tank

WELL NAME: Rock Tank Unit #4

FORMATION: Strawn

LOC: 1650' FSL & 1650' FEL
SEC: 1
TWP: 23-S RGE: 24-E

COUNTY: Eddy
STATE: NM

GL: 4011'
KB to GL: 19.0'
DF to GL: 18.0'

CURRENT STATUS: Shut-In
API NO: 30-015-20320

8-5/8", 24 #/ft, K-55 csg
 set @ 2483' w/ 950 sxs.
 Top job from 900' with
 200 sxs cmt in 3 stages
 bringing TOC to surf.
 11" hole.

TOC above 2280' by CBL log
 dated May 30, 2012

DV Tool @ 5502'

DV Tool @ 8510'

CICR @ 9815'

Junked Otis "PL" pkr @ 9,855'

U. Morrow Perfs 9902' - 10060'
 Cmt Sqz'd w/ CICR @ 9815'

CIBP @ 10075' w/ 10' cmt


Otis "WB" pkr @ 10,089'

Otis "WB" pkr @ 10,100'

L. Morrow Perfs 10200' - 44'

5-1/2", 17 #/ft, N-80 csg
 set @ 10,405' w/ 1250 sxs cmt
 in 3 stages. Est. TOC 2950'
 by calc. 7-7/8" Hole.

FILE: 2012_0531_RT_4_DIA.XLS
JAL 11-29-2012



Tubing Detail: (5-31-2012)

17.00'	KB
8,813.93'	282 Jts 2-3/8" 4.7 #, N-80, 8-rd EUE
1.10'	2-3/8" API Seat Nipple
8,832.03'	

Sqz'd Perfs
 8334' - 78'
 8398' - 416'

Perfs
 9015' - 22'
 9174' - 80'

Sqz'd Perfs
 9902' - 12'
 10016' - 26'
 10034' - 60'

Perfs (4 spf)
 10200' - 12'
 10216' - 28'
 10233' - 44'

CIBP @ 10,600' capped w/ 75' cmt.

WELL DATA SHEET

FIELD: Rock Tank

WELL NAME: Rock Tank Unit #4

FORMATION: Strawn

LOC: 1650' FSL & 1650' FEL
SEC: 1
TWP: 23-S RGE: 24-E

COUNTY: Eddy
STATE: NM

GL: 4011'
KB to GL: 19.0'
DF to GL: 18.0'

CURRENT STATUS: Shut-In
API NO: 30-015-20320

PROPOSED Plugged & Abandoned

8-5/8", 24 #/ft, K-55 csg
set @ 2483' w/ 950 sxs.
Top job from 900' with
200 sxs cmt in 3 stages
bringing TOC to surf.
11" hole.

TOC above 2280' by CBL log
dated May 30, 2012

DV Tool @ 5502'

DV Tool @ 8510'

CICR @ 9815'

Junked Otis "PL" pkr @ 9,855'

U. Morrow Perfs 9902' - 10060'
Cmt Sqz'd w/ CICR @ 9815'

CIBP @ 10075' w/ 10' cmt

Otis "WB" pkr @ 10,089'

Otis "WB" pkr @ 10,100'

L. Morrow Perfs 10200' - 44'

5-1/2", 17 #/ft, N-80 csg
set @ 10,405' w/ 1250 sxs cmt
in 3 stages. Est. TOC 2950'
by calc. 7-7/8" Hole.

PBTD @ 10365'

FILE: 2012_0531_RT_4_PAA.XLS
JAL 11-29-2012

TD @ 10,921'

Sqz'd Perfs
8334' - 78'
8398' - 416'

Perfs
9015' - 22'
9174' - 80'

Sqz'd Perfs
9902' - 12'
10016' - 26'
10034' - 60'

Perfs (4 spf)
10200' - 12'
10216' - 28'
10233' - 44'

CIBP @ 10,600' capped w/ 75' cmt.

E. G. L. Resources, Inc.
PO Box 10886
Midland, TX 79702

RE: NMNM0272711; Rock Tank Unit No. 4 (API 3001520320)
1650' FSL & 1650' FEL, Sec. 1, T23S-R24E
Eddy County, New Mexico

Abandonment Conditions of Approval;

1. OK
2. WOC tag
3. OK
4. OK
 - a. Add plug, from 7841'-7661' (top Wolfcamp)
5. OK
 - a. Add plug, from 3860'-3720' (top Bone Spring)
6. OK
 - a. Add Plug, perforate @ 1570' and squeeze cement from 1570'-1470' (top Delaware). WOC tag.
7. Perforate @ 60' and squeeze cement to surface leaving casing full.
8. OK
9. OK

If you have questions, please contact Jim Amos at 505-234-5909.

J. Amos
4/29/13

BUREAU OF LAND MANAGEMENT
Carlsbad Field Office
620 East Greene Street
Carlsbad, New Mexico 88220
575-234-5972

Permanent Abandonment of Federal Wells
Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within **ninety (90)** days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

2. **Notification:** Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.

3. **Blowout Preventers:** A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. **Mud Requirement:** Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.

5. **Cement Requirement:** Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. **Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.**

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Dry Hole Marker: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). **The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.**

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

7. Subsequent Plugging Reporting: Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**

8. Trash: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

J. Amos 3/6/11



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office
620 E. Greene St.
Carlsbad, New Mexico 88220-6292
www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Inspection & Enforcement

Jim Amos
Supervisory Environmental Protection Specialist
575-234-5909, 575-361-2648 (Cell)

Mike Burton
Environmental Protection Specialist
575-234-2226

Jeffery Robertson
Natural Resource Specialist
575-234-2230

Jennifer Van Curen
Environmental Protection Specialist
575-234-5905

Doug Hoag
Civil Engineering Technician
575-234-5979

Linda Denniston
Environmental Protection Specialist
575-234-5974

Permitting

Cody Layton
Natural Resource Specialist
575-234-5959

Trishia Bad Bear
Natural Resource Specialist
575-393-3612

Todd Suter
Surface Protection Specialist
575-234-5987

Tanner Nygren
Natural Resource Specialist
575-234-5975

Amanda Lynch
Natural Resource Specialist
575-234-5922

Leglon Brumley
Environmental Protection Specialist
575-234-5957

Realty, Compliance

Randy Pair
Environmental Protection Specialist
575-234-6240