

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

OCD Artesia

FORM APPROVED
OMB No. 1004-0137
Expires: July 31, 2010

SUNDRY NOTICES AND REPORTS ON WELLS
**Do not use this form for proposals to drill or to re-enter an
abandoned well. Use Form 3160-3 (APD) for such proposals.**

5. Lease Serial No.

NM109644 **LC046119A**

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE – Other instructions on page 2.

1. Type of Well

☐ Oil Well

☐ Gas Well

☒ Other Injection Well

2. Name of Operator
Beach Exploration, Inc.

7. If Unit of CA/Agreement, Name and/or No.
NMNM106832X

8. Well Name and No.
WEST HIGH LONESOME UNIT # 27

9. API Well No.
30-015-25495

3a. Address
800 N. Marienfeld, Suite 200, Midland, TX 79701

3b. Phone No. (include area code)
432 683 6226

10. Field and Pool or Exploratory Area
W. HIGH LONESOME QUEEN

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1,650 FNL, 330 FWL, Sec 20, Unit E, T 16 S, R 29 E

11. Country or Parish, State
EDDY COUNTY, NM

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleate horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleation in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

WHL #27 – Plugging Procedure

1. RU Pluggers. ND wellhead. NU BOP. **25**
2. Run 2 3/8" tbg to PBTD (1720'). Pump 30sx Class C cmt plug inside 5 1/2" csg on top of CIBP at 1730' (had 10' cmt on top). **25 sx min.**
3. Load hole with 9.5 ppg mud. POOH with tbg.
4. RU wireline and perforate 5 1/2" csg at 828'. Run pkr and tbg and squeeze 30sx Class C cmt plug (combination Yates and Base of Salt plug). If can't pump into sqz perfs, pump 30sx plug from 878' inside 5 1/2" csg. WOC. Tag plug at 728' or less. POOH with tbg.
5. RU wireline and perforate 5 1/2" csg at 348'. Run pkr and tbg and squeeze 30sx Class C cmt plug (combination 8 5/8" shoe and Top of Salt plug). If can't pump into sqz perfs, pump 30sx plug from 398' inside 5 1/2" csg. WOC. Tag plug at 225' or less. POOH with tbg.
6. Pull tbg to 132'. Squeeze 50sx Class C cmt plug in 5 1/2" csg (old leak between 75' and 82'). Bring plug to surface.
7. POOH. ND BOP. Cut 8 5/8" and 5 1/2" csg off 3' below ground level. Top off with cmt if necessary.
8. Install 4" dry hole marker with 4' above ground with required info stenciled on pipe.

Estimate starting plugging operations no later that July 15, 2013.

Accepted for record
NMOC

RECLAMATION PROCEDURE
ATTACHED

SEE ATTACHED FOR
CONDITIONS OF APPROVAL
RECEIVED
MAY 13 2013
NMOC ARTESIA

14. I hereby certify that the foregoing is true and correct.

Name (Printed/Typed)

Jack M. Rose

Title Engineer

Signature

Date 04/19/2013

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

James A. Davis

Title

SEPS

Date

5-7-13

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

CFO

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Calc TOC 43'
yld 1.32 50% exc

Salt
@275'

8 5/8"
@298'

Yates
@778'

Queen
@1518'

Penrose
@1772'

CIBP at 1730'

5 1/2"
@1920'
TD 1925'

TOC Surf
cmt 30' fr surf
5 yds rdy mix

Bot of tbq at 635'
w/SN

Penrose Perfs
1774' - 1793'

WHL #27 (Renee Federal #3)

GL: 3,638
KB: 3,644
TD: 1,925
PBD: 1,920
Fr. Wtr: 330 from W
Legal: 1,650 from N
Section: 20-E
Township: 16S
Range: 29E
County: Eddy

Status: Active Injection
Perfs: 1774' - 1793'
API: 30-015-25495
NM Lse: NMLC046119A
Field: High Lonesome (Queen)
Logs: GR, Neu, Den
Archeological: none

Casing	Wt	Type	Set	Cmt	Hole	TOC	Method
8 5/8"	24.00		298	280	12 1/4"	Surf	30'+5yds rdy mx
5 1/2"	14.00		1,920	375	7 7/8"	43	Calc 50% exc

4-Dec-85 Spud well
McClellan Oil Corp. - Renee Federal #3

18-Dec-85 Penrose Completion
Perf (1774'-1793') 9 holes 0.4" (1774,75,77,79,80,81,91,92 and 93)
acid w/1Mgal 10%, frac w/30Mgal gel wtr 16.5M# 20/40+32.5M# 12/20 sand
IP pumping 85 BOPD 5 BWPD 25 MCFPD 294 GOR 34 API

1-Oct-94 Beach purchased well

1-Dec-01 West High Lonesome Unit #27
Convert to Injection

21-May-02 Treated down 2 3/8 x 5 1/2 annulus w/250gal xylene

23-May-02 Pulled and laid down rods and pump. Press tst'd tbq to 2500psi. RIH w/bit & scraper and CO to 1816'. Acidized Penrose w/300gal 15% NEFE acid. Well on vacuum. Laid down tbq and sent to Rice Eng for Duo-10 lining.

17-Jul-02 RIH w/5 1/2" PC AD-1 pkr, PC SN, 53 jts 2 3/8" J-55 Duo-10 lined tbq. Bottom of pkr 1717'. Loaded backside w/pkr fluid and tested integrity. OK

26-Jul-02 OCD conducted inj well MIT. Passed

21-Feb-12 Well failed MIT test by Richard Inge (OCD) csg would take water above 200 psi

11-Apr-12 Flowed well back to btry for three weeks. POOH w/inj string and set CIBP at 1700'. Found leak in 5 1/2" csg between 75' and 82'. Test below 82' to 1500psi Pumped into leak in 5 1/2" and circ out 8 5/8". Spotted 2 bbl of cmt Class C w/2% CaCl2 at 103' to surf. Pumped 3.5 bbl of cmt down 5 1/2" csg and had full circ out 8 5/8". Circ good cmt out 8 5/8", SI 8 5/8" valve and press 5 1/2" csg to 200 psi. Bled to 110 psi and held that press overnight.

14-Apr-12 Drld cmt from 9' to 112'. Tested csg and losing 10 psi every 2 min. Drld CIBP at 1700'. CO to 1830'. POOH. RIH w/original injection string, circ 45 bbl of pkr fluid and set pkr w/13 pts. Press csg to 110 psi and still had 108 psi 2 days later. Test csg and pumping 0.5 bpm at 400 psi.

19-Apr-12 Decision to TA well. POOH w/injection string. Set 5 1/2" CIBP at 1730' and dump bailed 10' cmt on top. RIH w/SN and 21 jts of 2 3/8" workstring open ended to 630'. Swabbed water out of well down to 520'. SI well. Moved DUO-10 lined injection tubing along with remainder of workstring (108 jts) to central btry yard.

Note: Will monitor flood performance for one year to determine if this injector is critical. If critical will try to repair, if not will P&A.


53 jts 2 3/8" 4.7# J-55 Duo-10 lined 1709.16 to cent btry

TUBING STRING 4/19/2012

# OF JTS	DESCRIPTION	LENGTH	FROM	TO
	Distance from KB to top of pipe	4.00	0.00	4.00
21	2 3/8" 4.7# tbq	630.00	4.00	634.00
1	2 3/8" SN	1.10	634.00	635.10

ROD STRING (none)

# OF JTS	SIZE	TYPE OF RODS	LENGTH
----------	------	--------------	--------



WHL #27 (Renee Federal #3) (Proposed P&A)

GL: 3,638
KB: 3,644
TD: 1,925
PBD: 1,920

Fr. Wtr:
Legal: 330 from W
1,650 from N

Section: 20-E
Township: 16S
Range: 29E
County: Eddy

Status: Active Injection
Perfs: 1774' - 1793'

API: 30-015-25495

NM Lse: NMLC046119A
Field: High Lonesome (Queen)

Logs: GR, Neu, Den

Archeological: none

Casing	Wt	Type	Set	Cmt	Hole	TOC	Method
8 5/8"	24.00		298	280	12 1/4"	Surf	30'+5yds rdy mx
5 1/2"	14.00		1,920	375	7 7/8"	43	Calc 50% exc

4-Dec-85 Spud well
McClellan Oil Corp. - Renee Federal #3

Penrose Completion

18-Dec-85 Perf (1774'-1793') 9 holes 0.4" (1774,75,77,79,80,81,91,92 and 93)
acid w/1Mgal 10%, frac w/30Mgal gel wtr 16.5M# 20/40+32.5M# 12/20 sand
IP pumping 85 BOPD 5 BWPD 25 MCFPD 294 GOR 34 API

1-Oct-94 Beach purchased well

1-Dec-01 West High Lonesome Unit #27
Convert to Injection

21-May-02 Treated down 2 3/8 x 5 1/2 annulus w/250gal xylene

23-May-02 Pulled and laid down rods and pump. Press tst'd tbg to 2500psi. RIH w/bit & scraper and CO to 1816'. Acidized Penrose w/300gal 15% NEFE acid. Well on vacuum. Laid down tbg and sent to Rice Eng for Duo-10 lining.

17-Jul-02 RIH w/5 1/2" PC AD-1 pkr, PC SN, 53 jts 2 3/8" J-55 Duo-10 lined tbg. Bottom of pkr 1717'. Loaded backside w/pkr fluid and tested integrity. OK

26-Jul-02 OCD conducted inj well MIT. Passed

21-Feb-12 Well failed MIT test by Richard Inge (OCD) csg would take water above 200 psi

11-Apr-12 Flowed well back to btry for three weeks. POOH w/inj string and set CIBP at 1700'. Found leak in 5 1/2" csg between 75' and 82'. Test below 82' to 1500psi
Pumped into leak in 5 1/2" and circ out 8 5/8". Spotted 2 bbl of cmt Class C w/2% CaCl2 at 103' to surf. Pumped 3.5 bbl of cmt down 5 1/2" csg and had full circ out 8 5/8". Circ good cmt out 8 5/8", SI 8 5/8" valve and press 5 1/2" csg to 200 psi. Bled to 110 psi and held that press overnight.

14-Apr-12 Drld cmt from 9' to 112'. Tested csg and losing 10 psi every 2 min. Drld CIBP at 1700'. CO to 1830'. POOH. RIH w/original injection string, circ 45 bbl of pkr fluid and set pkr w/13 pts. Press csg to 110 psi and still had 108 psi 2 days later. Test csg and pumping 0.5 bpm at 400 psi.

19-Apr-12 Decision to TA well. POOH w/injection string. Set 5 1/2" CIBP at 1730' and dump bailed 10' cmt on top. RIH w/SN and 21 jts of 2 3/8" workstring open ended to 630'. Swabbed water out of well down to 520'. SI well. Moved DUO-10 lined injection tubing along with remainder of workstring (108 jts) to central btry yard.

Note: Will monitor flood performance for one year to determine if this injector is critical. If critical will try to repair, if not will P&A.

53 jts 2 3/8" 4.7# J-55 Duo-10 lined 1709.16 to cent btry

TUBING STRING 4/19/2012

# OF JTS	DESCRIPTION	LENGTH	FROM	TO
	Distance from KB to top of pipe	4.00	0.00	4.00
21	2 3/8" 4.7# tbg	630.00	4.00	634.00
1	2 3/8" SN	1.10	634.00	635.10

ROD STRING (none)

# OF JTS	SIZE	TYPE OF RODS	LENGTH
----------	------	--------------	--------

BUREAU OF LAND MANAGEMENT
Carlsbad Field Office
620 East Greene Street
Carlsbad, New Mexico 88220
575-234-5972

Permanent Abandonment of Federal Wells
Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within ninety (90) days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

2. Notification: Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.

3. Blowout Preventers: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. Mud Requirement: Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of brine water. Minimum nine (9) pounds per gallon.

5. Cement Requirement: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. **Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.**

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Dry Hole Marker: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). **The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.**

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

7. Subsequent Plugging Reporting: Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**

8. Trash: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

J. Amos 3/6/11



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office
620 E. Greene St.
Carlsbad, New Mexico 88220-6292
www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Inspection & Enforcement

Jim Amos
Supervisory Environmental Protection Specialist
575-234-5909, 575-361-2648 (Cell)

Mike Burton
Environmental Protection Specialist
575-234-2226

Jeffery Robertson
Natural Resource Specialist
575-234-2230

Jennifer Van Curen
Environmental Protection Specialist
575-234-5905

Doug Hoag
Civil Engineering Technician
575-234-5979

Linda Denniston
Environmental Protection Specialist
575-234-5974

Permitting

Cody Layton
Natural Resource Specialist
575-234-5959

Trishia Bad Bear
Natural Resource Specialist
575-393-3612

Todd Suter
Surface Protection Specialist
575-234-5987

Tanner Nygren
Natural Resource Specialist
575-234-5975

Amanda Lynch
Natural Resource Specialist
575-234-5922

Leglon Brumley
Environmental Protection Specialist
575-234-5957

Realty, Compliance

Randy Pair
Environmental Protection Specialist
575-234-6240