Fortre 3160-5 * (August 2007)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMEN

FORM APPROVED OMB NO. 1004-0135

Expires: July 31, 2010

11. County or Parish, and State

EDDY COUNTY, NM

٥.	Lease Serial No.	
	NMLC029419A	

SUNDRY NOTICES AN Do not use this form for pro abandoned well. Use form 3	Near Senai No. NMLC029419A If Indian, Allottee or Tribe Name If Unit or CA/Agreement, Name and/or No.	
SUBMIT IN TRIPLICATE - Oth		
Type of Well	N	8. Well Name and No. SKELLY 46
Name of Operator LINN OPERATING INC E-Mail:	Contact: TERRY B CALLAHAN tcallahan@linnenergy.com	9. API Well No. 30-015-05357
3a. Address 600 TRAVIS STREET, SUITE 5100 HOUSTON, TX 77002	3b. Phone No. (include area code) Ph: 281-840-4000	10. Field and Pool, or Exploratory GRAYBURG JACKSON;SR-Q-G-S

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
☑ Notice of Intent☐ Subsequent Report☐ Final Abandonment Notice	☐ Acidize ☐ Alter Casing ☐ Casing Repair ☐ Change Plans ☐ Convert to Injection	☐ Deepen ☐ Fracture Treat ☐ New Construction ☑ Plug and Abandon ☐ Plug Back	☐ Production (Start/Resume) ☐ Reclamation ☐ Recomplete ☐ Temporarily Abandon ☐ Water Disposal	☐ Water Shut-Off ☐ Well Integrity ☐ Other

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

SPOKE TO JIM AMOS (BLM) ON 8/19/2013 AND WAS GIVEN VERBAL APPROVAL TO PROCEED WITH PLUGGING OF THE SKELLY #46. THE PLUGGING PROCEDURES ARE AS FOLLOWS:

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

32.821908 N Lat, 103.850756 W Lon

Sec 22 T17S R31E Mer NMP SENE 1980FNL 560FEL

Skelly 46 Procedure ? PA (Briklynd Briggs 8/19/13)
Have 760sxs class C neat on location. Cmt will be 14.8lb/gal Class C neat with a 1.33cf/sx yield

1. Test rig anchors prior to rigging up.

2. MIRU. Check all pressures (tubing, casing, braden head)
3. Bleed off any pressure as necessary
4. NU BOP, POOH w/ everything. Stand back tubing. USE 2-3/8? work string going forward
5. RUWL RIH w/ CICR and set @ 2300?

6. Sting into CICR pump 25sxs Class C neat

7. Sting out CICR

RECLAMATION PROCEDURE ATTACHED

SEE ATTACHED FOR CONDITIONS OF APPROVAL

14. I hereby certify	that the foregoing is true and correct. Electronic Submission #217669 verific For LINN OPERATING I Committed to AFMSS for processing	NC, sen	it to the Carlsbad		
Name(Printed/T	yped) TERRY B CALLAHAN	Title	REG COMPLIANCE	SPECIALIST III	()
Signature	(Electronic Submission)	Date	08/21/2013	Rock	Total Control
	THIS SPACE FOR FEDERA	AL OR	STATE OFFICE US	SE TOWNS	<u></u>
Approved By	Panes a. amos	Title	SEAS		Date 8-24-13
certify that the applica	al, if any, are attached. Approval of this notice does not warrant or ant holds legal or equitable title to those rights in the subject lease he applicant to conduct operations thereon.		. CFB		

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Additional data for EC transaction #217669 that would not fit on the form

32. Additional remarks, continued

8. Spot 50sx cmt plug from 2300?-1565? WOC and Tag 9. RUWL RIH to 700? Perf 5 ft w/ 2spf

10. POOH RDWL

11. Squeeze 210sx from 700-580? WOC and Tag
12. RUWL RIH to 250? Perf 5? w/ 2spf of deep penetrating perfs

13. POOH RDWL

14. Squeeze 210sxs plug from 250? to surface

15. WOC 24hrs.

16. Cut off well head and weld on a ground level dry hole marker. Back fill cellar, cut off dead men and clean location.

Contacts:

Engineer ? Briklynd Briggs (832) 723-4867 Foreman ? Joe Hernandez (575) 942-9492 Site supervisor ? Tommy Snodgrass (575) 390-0716, (575) 390-3161

ATTACHED IS A COPY OF THE PROCEDURES AND THE PROPOSED WELLBORE DIAGRAM

' well Name! Skelly Unit # 46

	Lucation:				
County:	(ddy Caunty				
Surface Loc:	H-22-175-31E 1980 FNL 560 FEL				
Lat/Long!	32.8219081787357 : 103.850756062716				
Field:	Grayburg				
	Elevations:				
GL:	3456'				
KB:	3867'				
KR-GLE-S-	11:				

Lossing Requirements: PFC Log 2200" - 2500" Welex Gamma-Collar Log (11/25/1961)

Oate	History
11/16/1961	Spud well. Set 6 5/6" 244 6-R EW I-55 cag set at 650' and cm1'd w/ 260 sacks.
11/22/1961	Reathed TD @ 3820'. Set 4 1/2' 11.6x 6-R SS J-550D casing @ 3620' and control w/ 400 sts. P67D 3811'. Perf d 4 1/2' 0D cag 3782' - 90' 6 3799' - 3808' - tit 68 holes, Troat'd perfs 3782' - 3808' w/ 1259 bbls IPASE oil 50 500R 20/40 sand & 1000 rais 15% teg acid. Swabbed and Lesled woll.
	Perfd 4 I/2" OD casing 3509'-14', 3518'-22', 3525-36', 3544'-53', 3574'-78', 3612'-16' (37'-tt) of 148 holes). Treat'd 3509'-3616' w/ 1534 bbis "stick oil", 50,0004 20/40 tand and 1750 gais 15% reg acid w/ 9085.
	Oil well test 543 BD, 0 BW in 24 hours, 1" choke
4/15/1965	Started Injecting wir into San Andres Formation through 4 \$/2" OO cig perfs 3509" - 3808".
5/15/1 96 7	Part d # 1/2" 00 csg w/ 2 595 @ 3202: 3207, 3226; 3271; 3387, 3384; 3381; 3307, 3327; 3384; 3384; 3384; 3389; 3410; 3416; 3458; 3485; 4187 holes. Treat d through parts 3202" 3485" w/2000 gals 15% reg acid & 24 85. Treat d crg 3202" - 3485" w/ 25,000 gals wir, 20,000# 20/40 sand & # 85
212511053	Completed as Lingle Injection, 32021-38081
3/26/1968	Completed at ling-emisection, 3222-1808
1/29/1579	Rain PFC log 2/00" - 2500". Perf d fron 7 Rivers, 1 SPF, 2301", 04", 07", 12", 14", 16", 25", 29", 12", 42", 46", 48", 54", 60", 62", 65", 67", 78", 82", 2418", 20", 28", 8, 31" - ml 23 holes. Treat'd w/ 3500 gais 15% NE HCL and 35 fs. Rain long string, Howco R-2 Pkr, 27 lys 2 3/8" 15g 640", Oils Dusk 6 1/2" Pkr, 70 jts. 1,66 CS Hydrill lbg. 2212" set at 3050", tension pkr at 3078", dust pkr 2239". Rain short string 74:ns. 1,66C3 Hydrilltubing 2219" test in dust his 4", 2339".
1/25/2002	RiH and tag filt @ 3365' Wash to 3500 Tag Par & cut it out. Wash to \$191. Circ hole clean
2/26/2001	All: w/4 1/2" CIBP. Could not get past 3317 PDH did not set CIBP. Perfd Grayburg 3269" - 717, 3310"- 12: 27; 41; 64; 85; 3339 - 3407; 1408 - 7418; 3466" - 1446; 3455; 3655" - 3407 - 811 w/2 2-3/8"4 4-1/2" 8-4 phs; 25 [13: 2-3/8"4 4-1/2" tandom tention phr 671 [15: 7-3/8" IPC Ubing. Set bottom phr @ 3055' & flog nbr @ 2736" - ciprolated 99 (bull all: Ruid. Text cas annulls to 5008 for 30 min.
2/27/2002	Place wall back on inj 300BWPD @ 1400s
4/27/2012	Fassed MiT. Pressured up to 500A 30 minutes.

Current		Well Name:	Shelly Unit # 46	
	Wellbore Diagram		Wall Type:	Injection
			Lease Type:	[ederal
			API No:	30-015-05357
			Spud Date:	11/16/1961
0.1	l (ann il	2 96 lss 2 3/8" spc tubing	Current Operator: WBD Update:	Leslie Ward - 4/3/2013
¥		26 ltt 5 3/8, the thoins	(WIDO OPERIE;	Cearse Mard - 4/3/ Vots
:: ::		of the appropriate		
_ :			Hole Size: Surface Casme:	8 % 8" 244 } 53 cet @ 650"
į,		<u>.</u> &	Cement Blend;	2AD rxs
- S - Mora Grant	25% I	k P	Returns: TOC:	Surface
∐ ل	1 1221 11	Ç.	1105-	
4		<u>}</u>	Hale Site: Intermediate Cosing;	K/A
_		Ì	1	
	#		Cement Blend:	
- 회			Returns: TDC:	ĺ
7				
3				
Nammonderman		201 € 550	Details of Perforations	
1 3			2/26/2002	3269' - 71', 3310' - 12', 37', 41', 84', 85', 3399' - 3402', 3408' -
1 2		7 ret & 220.		3419', 3446' - 3448', 3458', 3485' - 3487'
			1/29/1979	1 595, 2301', 04', 07', 12', 14', 16', 25', 29', 32', 42', 46', 48', 54', 60', 62', 65', 67', 78', 82', 2416', 20', 28', 8, 31'-til 23 holes
			5/15/1967	3202', 3207', 3228', 3271', 3287', 3304', 3311', 3320' 3327',
‡				3341', 3384', 3399', 3410', 3416', 3446', 3456', 3485''
Ħ .			11/22/1961	3509' - 3514', 3518' - 3522', 3525' - 3536', 3544' - 3553', 3574' - 1578', 3612' -3616', 3637'
		TOC 1706' [Temp Survey]	11/22/1961	3782*-3790", 3799" - 3808" (66 holes)
-		Pk1 2236'		
] (· •	2301'-2431'		Tubing Detail
] }			. Joints	Description
-				
1 :		P&r 3055'	L.,	<u> </u>
_ [<u> </u>	3202' - 3787'		Rad Cetail (top to bottom)
-(6	يًا لِ	3304" + 3399"	Rode	Description
-	i #	1104.+ 1123,		
√l ń	5 5	3410 3482,	 	
]]		Perm Par 3498' partially cem	oved?	
1 8	قر.	3509' + 3514'		
- 6	; <u> </u>	3518'+ 3522'	Pumping Unit:	
] :				
-		3525' • 3536'		
- 4		3544" - 3553"	Hale Sire:	\$ 5/8"
1 6		3574' - 3578'	Production Casing: Capacity (bb/ft):	4 1/2" 11.60 j.55 tet @ 3820"
-	! [3615 3616.	Coment Bland:	400 ses
1 5	1 [1637	Returns:	FOC 1706' (Temp Survey)
		3782' - 3790'	Lead:	l
1 6	, <u> </u>	3799° - 1808°	¥aй:	1
1 5) [7 Control 24341
d Ž	<u>l</u>	prod cig iet @ 3820'		Top Grayburg 3124' Top San Andrea 3492'
-				

TD 3820' PBTD 3813'

Skelly 46 Procedure - PA (Briklynd Briggs 8/19/13)

Have 760sxs class C neat on location. Cmt will be 14.8lb/gal Class C neat with a 1.33cf/sx yield

- 1. Test rig anchors prior to rigging up.
- 2. MIRU. Check all pressures (tubing, casing, braden head)
- 3. Bleed off any pressure as necessary
- 4. NU BOP, POOH w/ everything. Stand back tubing. USE 2-3/8' work string going forward
- 5. RUWL RIH w/ CICR and set @ 2300'
- 6. Sting into CICR pump 25sxs Class C neat
- 7. Sting out CICR
- 8. Spot 50sx cmt plug from 2300'-1565' WOC and Tag
- 9. RUWL RIH to 700' Perf 5 ft w/ 2spf
- 10. POOH RDWL
- 11. Squeeze 210sx from 700-580' WOC and Tag
- 12. RUWL RIH to 250' Perf 5' w/ 2spf of deep penetrating perfs
- 13. POOH RDWL
- 14. Squeeze 210sxs plug from 250' to surface
- 15. WOC 24hrs.
- 16. Cut off well head and weld on a ground level dry hole marker. Back fill cellar, cut off dead men and clean location.

Contacts:

Engineer - Briklynd Briggs (832) 723-4867

Foreman - Joe Hernandez (575) 942-9492

Site supervisor - Tommy Snodgrass (575) 390-0716, (575) 390-3161

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification</u>: Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

J. Amos 3/6/11

Requirements for ground level dry hole markers <u>Well Identification Markers</u> Conditions of Approval (COA)

The BLM Carlsbad Field Office (CFO) Conditions of Approval (COA) Requires that ground level dry hole markers be placed on well within the Lesser Prairie Chicken habitat area. The dry hole markers will be to the following specifications. The operator will construct the markers as follows:

- 1. An 8 inch X 8 inch steel plate 1/8 to 3/16 of an inch thick is to be placed on the old dry hole marker stand pipe 2 inches from ground level, in the Lesser Prairie Chicken habitat area.
- 2. Steel plate may be welded or bolted approximately 2 inches from ground level on the stand pipes. If plates are bolted to the stand pipe, the person installing the plate will be required to weld a pipe collar on the plate and place a minimum of two set screws/bolt on each collar. Aluminum data plates may be bolted with minimum ¼ inch bolt and locking nuts or self tapping fine threaded screws. A minimum of one in each corner is to be installed on each plate.
- 3. An 8 inch x 8 inch aluminum plate, which is 12 gauge or .080 sign material (1/8 inch aluminum plate may be used in place of the .080 plate) with the required information for that well stamped or engraved in a minimum 3/8 inch tall letter or number.
- 4. The following information will be stamped or engraved on the 8 inch X 8 inch aluminum plate in the following order.
 - a. First row: Operators name
 - b. Second row: Well name and number
 - c. Third row: Legal location to include ¼ ¼, Section, Township, and range. If the legal location cannot be placed on one row it can be split into two rows with the ¼ ¼ (example: 1980 FNL 1980 FWL) being on the top row.
 - d. Fourth row: Lease Number and API number.
 - i. Example marker plate: (attached)

NMOCD Order No. R-12965 also required the operator to notify NMOCD when this type of dry hole marker is used. This can be done on the subsequent report of abandonment which is submitted to the BLM after the well is plugged. State that a ground level dry hole marker was installed as required in the COA's from the BLM.



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, redistribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- 1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Inspection & Enforcement

Jim Amos Supervisory Environmental Protection Specialist 575-234-5909, 575-361-2648 (Cell)

Mike Burton
Environmental Protection Specialist
575-234-2226

Jeffery Robertson
Natural Resource Specialist
575-234-2230

Jennifer Van Curen Environmental Protection Specialist 575-234-5905

Doug Hoag Civil Engineering Technician 575-234-5979

Linda Denniston Environmental Protection Specialist 575-234-5974

Solomon Hughes Natural Resource Specialist 575-234-5951

Permitting

Cody Layton Natural Resource Specialist 575-234-5959

Trishia Bad Bear Natural Resource Specialist 575-393-3612

Todd Suter Surface Protection Specialist 575-234-5987

Tanner Nygren Natural Resource Specialist 575-234-5975

Amanda Lynch Natural Resource Specialist 575-234-5922

Legion Brumley Environmental Protection Specialist 575-234-5957

Realty, Compliance
Randy Pair
Environmental Protection Specialist
575-234-6240