Submit LCopy To Appropriate District Office	State of New Mexico		Form C-103 Revised July 18, 2013		
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natural Resources		WELL API NO.		
<u>District II</u> - (575) 748-1283	OIL CONSERVATION DIVISION		30-015-29710		
811 S. First St., Artesia, NM 88210 District_III – (505) 334-6178	1220 South St. Francis Dr.		5. Indicate Type of Lease		
1000 Rio Brazos Rd., Aztec, NM 87410			STATE [FEE 🛛	
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	Santa Fe, NM 87505		6. State Oil & Gas	Lease No.	
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or U	Jnit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			Patrick API		
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			8. Well Number		
1. Type of Well: Oil Well Gas Well Other			6		
2. Name of Operator				9. OGRID Number	
Yates Petroleum Corporation			025575		
3. Address of Operator				10. Pool name or Wildcat	
105 South Fourth Street, Artesia, NM 88210			Dagger Draw; Upper Penn, North		
4. Well Location Unit Letter F: 1980 feet from the North line and 1980 feet from the West line				he <u>West</u> line	
Section 10 Township 19S Range 25E NMPM Eddy County					
11. Elevation (Show whether DR, RKB, RT, GR, etc.)					
tari ya waka waka waka waka waka waka waka w	3486	<u>'GR</u>		5 A 000 5 12 4 Y	
12. Check	Appropriate Box to Indicate N	ature of Notice,	, Report or Other D	ata	
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:					
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WOR					
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING				AND A	
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT				74.127.	
DOWNHOLE COMMINGLE					
CLOSED-LOOP SYSTEM					
OTHER:		OTHER:			
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date					
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.					
proposed completion of recompletion.					
Yates Petroleum Corporation plans to plug and abandon this well as follows:					
1. MIRU all safety equipment as needed. NU BOP. No casing recovery will be attempted.					
2. Run a GR and set a CIBP at 7684' and cap it with 25 sx Class "H" cement. This will place a plug over Canyon perfs. WOC and tag.					
3. Load hole with plugging mud. Spot a 35 sx Class "C" cement plug from 5478'-5678', this will leave a plug across Wolfcamp top.					
4. Load hole with plugging mud. Spot a 35 sx Class "C" cement plug from 3302'-3502', this will leave a plug across Bone Spring top.					
5. Load hole with plugging mud. Spot a 35 sx Class "C" cement plug from 2099'-2299', this will leave a plug across Glorieta top.					
6. Load hole with plugging mud. Spot a 70 sx Class "C" cement plug from 834'-1234', this will leave a plug across surface casing shoe. WOC and tag.					
7. Spot a 55 sx Class "C" cement plug from 300' up to surface, this will form the surface plug. WOC and tag plug.					
8. Cut off wellhead, install dry hole marker and clean location.					
	г	Approved for plugging	of well hore only.		
Wellbore schematics attached		Liability under bond is	retained pending receipt	NM OIL CONSERVATION	
		of C-103 (Subsequent 1	Report of Well Plugging) OCD Web Page under	ARTESIA DISTRICT	
Spud Date:		which may be found at iFOtms, www.cmnrd.sta		AUG 04 2016	
WELL MUST BE PLU	0 BED BY 8/4/2	017		RECEIVED	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.					
SIGNATURE TITLE Regulatory Reporting Supervisor DATE August 2, 2016					
Type or print name Tina Huerta E-mail address: tinah@yatespetroleum.com PHONE: 575-748-4168					
For State Use Only					
APPROVED BY: Mulet 2 Arch _ TITLE COMPLIANCE OFFICER DATE 8/4/2016					
APPROVED BY: fourt 2 by TITLE COMPLIANCE OFFICER DATE 8/4/2016 Conditions of Approval (if any): SEE ATTACHED COA-5					
& SEE ATTACHED COA-S					

WELL NAME: PATRICK API No. 6 FIELD: Dagger Draw LOCATION: Unit letter F, 1980' FNL & 1980' FWL of Section 10-19S-25E Eddy Co., NM GL: 3486' **ZERO**: 17' **KB**: 3503' **CASING PROGRAM** SPUD DATE: 2/12/98 COMPLETION DATE: 3/16/98 COMMENTS: API No.: 30-015-29710 9-5/8" 36# J55 STC 1,184' Surface 7" 26# J55 693' 7" 23# J55 4,583' 7" 26# J55 2,063' 7" 26# N80 844' 8,170' Bottom 14-3/4" Hole **Before TOPS** 9-5/8" @ 1,184' w/1,300 sx SA 792' 1*ed to surface w\ 300 sx Glorieta 2,249 Bone Spring 3,452' Wolfcamp 5,628' Canyon 7,632' 8-3/4" Hole -Canyon Perfs: 7,734-7,802' (28) 7" @ 8,170' Not to Scale w/ 1,100 sx (Circ) 7/6/16 PBTD: 8,188' **JMH** TD: 8,133'

WELL NAME: PATRICK API No. 6 __FIELD: Dagger Draw LOCATION: Unit letter F, 1980' FNL & 1980' FWL of Section 10-19S-25E Eddy Co., NM **GL**: 3486' ____ ZERO: 17' KB: 3503' **CASING PROGRAM** SPUD DATE: 2/12/98 COMPLETION DATE: 3/16/98 **COMMENTS**: API No.: 30-015-29710 9-5/8" 36# J55 STC 1,184' Surface 7" 26# J55 693' 55sx Class "C" plug 7" 23# J55 4.583' from 0' - 300' 7" 26# J55 2,063' Surface plug. 7" 26# N80 844' 8,170' Bottom. 14-3/4" Hole **After** 70sx Class "C" plug from 834' - 1,234' Across CSG shoe. TOPS 9-5/8" @ 1,184' w/1,300 sx SA 792' 1 ed to surface w\ 300 sx Glorieta 2,249' Bone Spring 3,452' 35sx Class "C" plug Wolfcamp 5,628' from 2,099' - 2,299' Across Glorieta Top 7,632' Canyon 35sx Class "C" plug from 3,302' - 3,502' Across Bone Springs Top 8-3/4" Hole 35sx Class "C" plug from 5,478' - 5,678' Across Wolfcamp Top CIBP @ 7,684'w\ 25 sx Class "H" cement Canyon Perfs: 7,734-7,802' (28) 7" @ 8,170' Not to Scale w/ 1,100 sx (Circ) 7/6/16 PBTD: 8,188' **JMH** TD: 8,133'

45 m

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below.

 ALL casing shoes, casing stubs, DV tools, attempted casing cut offs, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 14. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 15. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 16. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.

- 17. Formations to be isolated with cement plugs are:
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 18. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, and cement will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and well number
- 3. API number
- 4. Unit letter
- 5. Quarter section (feet from North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging date
- 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)