

District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 A. First St., Artesia, NM 88210
District III
1000 Rio Brazos Rd. Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION

1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-39020
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease NO. B0-2071-0032
7. Lease Name or Unit Agreement Name Empire Abo Unit
8. Well Number 408
9. OGRID Numer 873
10. Pool Name Empire; Abo (22040)
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3675' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR DEEPEN OR PLUG BACK TO A DIFFERENT RESERVIOR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well Gas Well Other

2. Name of Operator
Apache Corporation

3. Address of Operator
303 Veterans Airpark Lane, Ste. 3000, Midland, TX 79705

4. Well Location
Unit Letter **O** : **140** feet from the **S** line and **2560** feet from the **E** line
Section **31** Township **17S** Range **28E** NMPM County **Eddy**

12. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	RECEIVED
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>		ALTERING CASING <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		P AND A <input type="checkbox"/>	
		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram or proposed completion or recompletion.

CONDITIONS OF APPROVAL ATTACHED

Approval Granted providing work is Completed by Oct 30, 2015

Approved for plugging of well bore only. Liability under bond is retained pending receipt of C-103 (Subsequent Report of Well Plugging) which may be found at OCD Web Page under Formis. www.cmrnd.state.nm.us/oed.

Apache Corporation proposes to P&A the above mentioned well by the attached procedure. A closed loop system will be used for all fluids from this wellbore and disposed of required by OCD Rule 19.15.17.

NM OIL CONSERVATION

ARTESIA DISTRICT

OCT 12 2016

NM OIL CONSERVATION

ARTESIA DISTRICT

OCT 30 2014

Spud Date:

RECEIVED

Rig Release Date:

WELL MUST BE PLUGGED BY 10/12/2017 OR A NEW C-103 SUBMITTED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Guinn Burks TITLE Sr. Reclamation Foreman DATE 10/22/14

Type or print name Guinn Burks E-mail add. guinn.burks@apachecorp.com PHONE: 432-556-9143

APPROVED BY: Robert J. Burd TITLE COMPLIANCE OFFICER DATE 10/12/2016

Conditions of Approval (if any):

** See Attached COAs*



WELL BORE INFO.

LEASE NAME	Empire Abo Unit
WELL #	408
API #	30-016-39020
COUNTY	Eddy, NM

0
632
1264
1895
2527
3159
3791
4423
5054
5686
6318

12 1/4" Hole
8 5/8" 24# @ 512'
w/ 410 sx to surf


DVT @ 2973'

CIBP @ 5450' w/ 35' cmt

CIBP @ 5765' w/ 30' cmt

CIBP set @ 5760' w/ 30' cmt, fell to 5797'

7 7/8" Hole
5 1/2" 17# @ 6318' w/ 710 sx
DVT @ 2973' w/ 580 sx to surf



Abo perms # 5500'-5602'

Abo perms @ 5770'-6032'

PBTD @ 5450'
TD @ 6318'



WELL BORE INFO.

LEASE NAME Empire Abo Unit
 WELL # 408
 API # 30-015-39020
 COUNTY Eddy, NM

PROPOSED PROCEDURE

0

12 1/4" Hole
 8 5/8" 24# @ 512'
 w/ 410 sx to surf

*PERF. @ 552
 AND SQUEEZE* ←

632

1264

1895

2527

3159

3791

4423

5054

5688

6318

DVT @ 2973'

CIBP @ 5450' w/ 35' cmt

CIBP @ 5765' w/ 30' cmt

CIBP set @ 5760' w/ 30' cmt, fell to 5797'

7 7/8" Hole
 6 1/2" 17# @ 6318' w/ 710 sx
 DVT @ 2973' w/ 580 sx to surf

PBTD @ 5450'
 TD @ 6318'

7. PUH & spot 65 sx Class "C" cmt from 650' to surf. (7 Rvs. Surface Shoe & Water Board)

6. PUH & spot 25 sx Class "C" cmt from 1225'-975' (Queen)

5. PUH & spot 45 sx Class "C" cmt from 2009'-1559' WOC/TAG (Grayburg/San Andres)

4. PUH & spot 25 sx Class "C" cmt from 3023'-2773' WOC/TAG (DV Tool)

3. PUH & spot 25 sx Class "C" cmt from 3678'-3428' (Glorieta & Yeso)

2. PUH & spot 25 sx Class "C" cmt from 4892'-4642' (Tubb)

1. MIRU, RIH & verify CIBP @ 5450', CIRC w/MLF & spot 25 sx Class "C" cmt from 5450'-5200' WOC/TAG (Abo)

Abo perms # 5500-5602

Abo perms @ 5770'-6032'

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
7. Produced water **will not** be used during any part of the plugging operation.
8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
10. **Class 'C' cement will be used above 7500 feet.**
11. **Class 'H' cement will be used below 7500 feet.**
12. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
13. **All Casing Shoes Will Be Perforated and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**
14. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
15. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

16. **When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set**
17. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag)**.
18. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
19. Any Production Formations will be isolated with cement plugs: Some of these are:
 - A) **Strawn, Fusselman, Devonian, Marrow, Atoka, Wolfcamp, Bone springs, Delaware, Abo, Glorieta, Any Salt Section, (Potash), Grayburg, Queen, Yates, Tubb, 7-Rivers**
 - B) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
20. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)