NM OIL CONSERVATION

ARTESIA DISTRICT

OCT 1 3 2016 Submit I Copy To Appropriate District Form C-103 State of New Mexico Revised July 18, 2013 Energy, Minerals and Natural Resources WELPEREIVED District 1 - (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240 District II - (575) 748-1283 30-015-22000 OIL CONSERVATION DIVISION 811 S. First St., Artesia, NM 88210 5. Indicate Type of Lease District III - (505) 334-6178 1220 South St. Francis Dr. FEE STATE X 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 District IV - (505) 476-3460 6. State Oil & Gas Lease No. 1220 S. St. Francis Dr., Santa Fe, NM 87505 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A **Empire South Deep Unit** DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 8. Well Number 13 1. Type of Well: Oil Well Gas Well X Other 2. Name of Operator 9. OGRID Number Matador Production Company 228937 3. Address of Operator 10. Pool name or Wildcat 5400 LBJ Freeway, Ste 1500 South Empire Morrow 4. Well Location Unit Letter feet from the West feet from the South line and __660 Section Township 175 Range NMPM FDDY County 11. Elevation (Show whether DR, RKB, RT, GR. etc.) 3646.0 GL 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK ALTERING CASING **TEMPORARILY ABANDON CHANGE PLANS** COMMENCE DRILLING OPNS. □ P AND A **PULL OR ALTER CASING** MULTIPLE COMPL П CASING/CEMENT JOB DOWNHOLE COMMINGLE **CLOSED-LOOP SYSTEM** OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. MIRU PU Blow well down, ND WH & NU BOP. POOH & LD TB, PKR 2. -7370' (WOLF CAMP) Set CIBP ~10,500' W/40 skx of cmt. WOC/TAG PUH and place balance plug ~7,000 W/60 sks of cmt on top. WOC/TAG - 2950'(50' BELOW SHOE) PUH and perf -5,820' sqz w/35 skx of cmt. WOC/TAG PUH and perf ~2,986 sqz w/30 skx of cmt. WOC/TAG PUH and place balance plug ~1,400' w/30 skx of cmt on top. WOC/TAG AOO PLUE-PERF @ 380-50 - WGEOTAL
PUH and perf ~150' sqz and circulate cmt to surface. WOC/TAG Cut off wellhead, verify cmt in annulus, and install NMOCD spec "Flat Phond is retained pending receipt ABOUT GROUND MARKER nema is renamen penaming necessity 10. RDMO PU, and aux equipment So tonug at OCD Mep bake nuger 11 Clean location of all debris, and prep location to initiate final reclamation procedures Current and Proposed wellbore schematics attached Liability und 5.C.103 (5u) Spud Date: 1/31/1977 Rig Release Date: which may BE PLUBBEN I hereby certify that the information above is true and complete to the best of my knowledge and belief. TITLE Production Engineer DATE 10/10/2016 Type or print name_Rakesh Patel E-mail address: rpatel@matadorresources.com PHONE: 575-623-6601 For State Use Only TITLE COMPLIANCE OFFICED DATE 10/14/2016 APPROVED BY Conditions of Approval (if any):

of SEE ATTACHED COA-S

Empire South Deep Unit #13
Empire Morrow South
Api #30-015-22000 #237350-013

N-30-17S-29E, Eddy County 660 FSL & 1432 FWL SEXSWX State Lease #B-7596 296.57 ac Elev. 3.646' (15') Matador Production Company


prepared by Rakesh Patel

DRAWING NOT TO SCALE.

Wellbore Status as of : 09/29/16 Spud: 1/31/1977

TD: 3/23/1977 11:060 EXISTING STATUS Completed: 4/7/1977

PBTD: 3/25/1977-10.960



Other well information:

Surface Casing: 8 jts 34 12-3/4"
Intermediate Casing: 58 jts 24 lb/ft & 13 jts 28 lb/ft, K-55, 8-5/8"
Production Casing: 23 jts 20 lb/ft, N-80, 5-1/2"
251 jts 17 lb/ft, N-80 5-1/2"

Empire South Deep Unit #13 Empire Morrow South

API #30-015-22000 #237350-013 N-30-17S-29E, Eddy County 660' FSL & 1432' FWL SEWSWW. State Lease #B-7596 296 57 ac Elev. 3,646' (15')

Matador Production Company

prepared by Rakesh Patel

DRAWING NOT TO SCALE

Wellbore Status as of : 09/29/16 Spud: 1/31/1977

PROPOSED STATUS

TD: 3/23/1977 11,060 Completed: 4/7/1977

PBTD: 3/25/1977 10:960

Perf +/- 150' and circulate cmt to surface

3801- PERF+34-WOLFTAL

Place to believe plug +/= 1400" W/30 skx of cmt on top

Perf +/- 2900 sqz W/30 skx of cmt 2,900' **295**8

Perf +/- 5820' sqz W/35 skx of cmt TOC @ 6,070

Place a balance plug +/- 2000' W/60 skx of cmt on top.

Set CIBP +/- 10,500 W/40 skx of cmt 10,570

MORROW PERFS:

4/6/1977 10,665' - 10,677' (48 shots)

PBTD: 10,960' TD: 11,060'

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. All Casing Shoes Will Be Perforated and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing
- 14. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 15. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 18. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 19. Any Production Formations will be isolated with cement plugs: Some of these are:
 - A) Strawn, Fusselman, Devonian, Marrow, Atoka, Wolfcamp, Bone springs, Delaware, Abo, Glorieta, Any Salt Section, (Potash), Grayburg, Queen, Yates, Tubb, 7-Rivers
 - B) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 20. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)