

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised July 18, 2013

Oil CONSERVATION DIVISION

1220 South St. Francis Dr.

Santa Fe, NM 87505

WELL API NO.

30-005-60955

5. Indicate Type of Lease

STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name  
Isler Fee

8. Well Number 001

9. OGRID Number 181156

10. Pool name or Wildcat  
Pecos Slope; ABO (Gas)

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

Scythian Ltd

3. Address of Operator

300 N Marienfeld, Suite 950, Midland, TX 79701

4. Well Location

Unit Letter D : 660 feet from the North line and 660 feet from the West line

Section 15 Township 7S Range 26E NMPM Chaves County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

3713 GL

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

DOWNHOLE COMMINGLE ☐

CLOSED-LOOP SYSTEM ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ P AND A ☒

CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1/17/17 - 1/20/17

1. RU WSU. NU BOP.

2. Ran gauge ring. Could not get below 2450'. RU reverse unit. TIH w/ bit & scraper to 4410'.

3. RU wireline. Set CIBP @ 4403'.

4. Circ. 10# gelled brine. Spotted 35' cement on top of CIBP.

5. WOC. Tagged TOC @ 4366'.

6. Perf. 2 squeeze holes @ 1414'. Squeeze 50 sx Class "C" cement. WOC. Tagged TOC @ 1260'.

7. Spotted 25 sxs plug @ 950'. WOC. TOC @ 796'.


8. Perf @ 100'. Squeeze cement. Circulated cement to surface.

9. Cut off well head, anchors. Install dry hole marker.

10. Clean location. Take fluid from steel work pit to disposal.

Spud Date:

Rig Release Date:



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Agent DATE 01/26/2017

Type or print name M.Y. Merchant E-mail address: mymerch@penrocoil.com PHONE: 575-492-1236

For State Use Only

APPROVED BY: [Signature] TITLE COMPLIANCE OFFICER DATE 1/30/17

Conditions of Approval (if any):