Submit 1 Copy To Appropriate District Office	State of New Mexico				Form C-103 Revised August 1, 2011		
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240				WELL API NO.	Terisod Tagast 1, 2011		
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION			30-015-20746 5. Indicate Type of I	ease		
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.			STATE 🖂	FEE		
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	Santa Fe, NM 8/303			6. State Oil & Gas L	ease No.		
SUNDRY NOT (DO NOT USE THIS FORM FOR PROPODIFFERENT RESERVOIR. USE "APPLIC PROPOSALS.)	7. Lease Name or UI ETZ STATE UN	IT					
1. Type of Well: Oil Well	Gas Well Other			8. Well Number	118		
Name of Operator COG OPERATING LLC				9. OGRID Number	299137		
3. Address of Operator 600 W. ILLINOIS, MIDLAND	TX 79701			10. Pool name or Wi	I		
4. Well Location				<u></u>			
Unit LetterN:_	_990feet from theS				heWESTline		
Section 16	Township 11. Elevation (Show whee	17S	Range 30E	NMPM	EDDY County		
	*	5' GR	KKB, KI, GK, eic.,	194 254 254 1			
	Appropriate Box to Ind	licate Na	ŕ	•			
NOTICE OF IN PERFORM REMEDIAL WORK □	ORT OF: TERING CASING □						
TEMPORARILY ABANDON		AND A					
PULL OR ALTER CASING DOWNHOLE COMMINGLE	MULTIPLE COMPL		CASING/CEMENT	ГЈОВ 🗌			
OTHER:			OTHER:		П		
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.							
 NOTIFY NMOCD 24 HRS. BEFORE MIRU. MIRU. ND WH, NU BOPE. SET CIBP@2450' AND SPOT 50SX OF CLASS "C" CEMENT FROM 2450'-2020'. WOC&TAG. (PERFS) CIRCULATE 9.5 PPG MLF AND TEST CASING. PERF@1052' AND SQUEEZE 30SX OF CLASS "C" CEMENT FROM 952'-1052'. WOC&TAG. (B.SALT) PERF@581' AND SQUEEZE 30SX OF CLASS "C" CEMENT FROM 481'-581'. WOC&TAG. (SHOE/T.SALT) PERF@60' AND SQUEEZE 20SX OF CLASS "C" CEMENT FROM SURFACE-60'. VERIFY CEMENT TO SURFACE. 							
(FW/SURFACE).							
8. CUTOFF WELLHEAD AT	ND ANCHORS 3 BELOW	SUKFA	CE. TOKN OVER	FOR RECLAMATIO	N.		
CLOSED LOOP CONTAI	NMENT SYSTEM WILL I	BE USED	FOR FLUIDS.	MM	OIL CONSERVATION ARTESIA DISTRICT		
Spud Date:		elease Dat			OCT 2 3 2017		
Well J I hereby certify that the information	The Pl		1 R.	10-23-18	RECEIVED		
I hereby certify that the information	above is true and complete	to the be	st of my knowledge	e and belief.	O CAMERO NEW EXCLUSION ST. Break 5-17		
SIGNATURE 4.				_DATE10/17/17			
Type or print nameM. LEE ROA				vices.comPHONE			
For State Use Only	_	- 1	٨٨				
APPROVED BY: DATE 10-23-17 Conditions of Approval (if any):							
APPROVED BY: See Attackel COA's DATE 10-23-17 Conditions of Approval (if any):							

WELLBORE DIAGRAM ETZ STATE #118 CURRENT


Created: Updated: Lease: Field: Surf. Loc.: Bot. Loc.: County: Status:	10/16/17 ETZ S GRAYBURG 990' FSL &		Well #: API Unit Ltr.: TSHP/Rng: Pool Code: Directions:	118
Surface Cas Size: Wt., Grd.: Depth: Sxs Cmt: Circulate: TOC: Hole Size:	8 5/8" 20# 531' 100 ? 11"			
FORMATION T.Salt B. Salt	TOPS 526' 1002'		7 Rive	ers perfs: 2070'-2076' squeezed w/100s)
Production of Size: Wt., Grd.: Depth: Sxs Cmt: Circulate: TOC: Hole Size:	Casing 5-1/2" 14/17 4048' 600 No 1165' EST. 7 7/8"	TD 405	Grayb	<u>መ</u> 2870' + 35' CMT. ON TOP ourg/San Andres perfs: 2523"-3962' (OA)

PBTD 4019'

WELLBORE DIAGRAM ETZ STATE #118 PROPOSED

Created: Updated: Lease: Field: Surf. Loc.:	GRAYBUR	By: LEE R. By: STATE G JACKSON k 1650' FWL	Well #: API Unit Ltr.: TSHP/Rng: Pool Code:	118 Lse. B-936 30-015-20746 N Section: 16 T17S / R301E OGRID: 229137
Bot. Loc.: County: Status:	EDDY	St.: NM	Directions:	
Surface Cas Size: Wt., Grd.: Depth: Sxs Cmt: Circulate: TOC: Hole Size:	sing 8 5/8" 20# 531' 100 ? ? 11"		MLF P&S	6 60'-SURFACE' W/20SX OF CMT. RIFY CMT TO SURFACE.
			MLF P&S	C&TAG. (SHOE//T.SALT) \$ 1052'-952' W/30SX OF CMT. C&TAG. (B.SALT)
FORMATION T.Salt B. Salt	TOPS 526' 1002'		CIBI	vers perfs: 2070'-2076' squeezed w/100s) P@2450' + 50SX CMT. FROM 2450'- D' WOC&TAG. (PERFS)
Production (Size: Wt., Grd.: Depth: Sxs Cmt: Circulate: TOC: Hole Size:	Casing 5-1/2" 14/17 4048' 600 No 1165' EST. 7 7/8"		CIBP	@2870' + 35' CMT. ON TOP burg/San Andres perfs: 2523"-3962' (OA)

COG Operating LLC



CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - 1) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least 1/2" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)