Form 316&-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR Carlsbad Field Office B NO. 1004-0137 BUREAU OF LAND MANAGEMENT OCD A FINAL FORM APPROVED OF THE INTERIOR CARLS FORM APPROVED OF THE

SUNDRY NOTICES AN	D REPORTS ON WELLS	$_{s}$ UUD	Artes	14 ase Senai No. 14 MNM85893

Do not use this form for proposals to drill or to re-enter an 6. If Indian, Allottee or Tribe Name abandoned well. Use form 3160-3 (APD) for such proposals. 7. If Unit or CA/Agreement, Name and/or No. SUBMIT IN TRIPLICATE - Other instructions on page 2 1. Type of Well 8. Well Name and No. CEDAR CANYON 21 FEDERAL COM 23H ☑ Oil Well ☐ Gas Well ☐ Other Name of Operator
OXY USA INC Contact: DAVID STEWART API Well No. 30-015-44191-00-X1 E-Mail: david_stewart@oxy.com 10. Field and Pool or Exploratory Area
CORRAL DRAW-BONE SPRING 3a. Address 3b. Phone No. (include area code) Ph: 432.685,5717 MIDLAND, TX 79710 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 11. County or Parish, State Sec 21 T24S R29E SWNW 1824FNL 141FWL EDDY COUNTY, NM 32.205242 N Lat, 103.997551 W Lon 12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF SUBMISSION TYPE OF ACTION □ Acidize □ Deepen ☐ Production (Start/Resume) ■ Water Shut-Off Notice of Intent □ Alter Casing ☐ Hydraulic Fracturing ☐ Well Integrity ☐ Reclamation ☐ Subsequent Report ☐ Casing Repair ☐ New Construction □ Recomplete Other Change to Original A ☐ Final Abandonment Notice □ Change Plans ☐ Plug and Abandon □ Temporarily Abandon □ Convert to Injection ☐ Plug Back ■ Water Disposal 13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection. OXY USA Inc. respectfully requests approval for the following changes from the approved permit: 1. OXY requests the option to contract a Surface Rig to drill, set surface casing, and cement for this well. If the timing between rigs is such that OXY would not be able to preset surface, the NM OIL CONSERVATION Primary Rig will MIRU and drill the well in its entirety per the APD. Please see the attached ARTESIA DISTRICT document for information on the spudder rig. OCT 16 2017 2. OXY proposes to drill out the surface casing shoe with a Direct Emulsion Water Based Mud which will consist of an external saturated brine phase with pH above 10 at all times, from 400' to PCP. This will eliminate the need for two mud systems, to manage both the salt and losses circulation interval in the intermediate/production hole section. RECEIVED 10-16-17 Accepted for record - NMOCD 14. I hereby certify that the foregoing is true and correct Electronic Submission #383511 verified by the BLM Well Information System For OXY USA INC, sent to the Carlsbad
Committed to AFMSS for processing by TENILLE ORTIZ on 08/08/2017 (17TO0027SE) Name (Printed/Typed) DAVID STEWART Title SR REGULATORY ADVISOR (Electronic Submission) Signature 08/02/2017 Date THIS SPACE FOR FEDERAL OR STATE OFFICE USE Date 10/04/2017 Approved By MUSTAFA HAQUE TitlePETROLEUM ENGINEER Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon. Office Carlsbad Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Additional data for EC transaction #383511 that would not fit on the form

32. Additional remarks, continued

Depth 0-400' 400-PCP PCP-TD Fluid Type Mud Weight Spud Mud 8.4-8.6 DEWBM 9.0-9.5 DEWBM (Brine/OBM-Contingency) 9.5-10.0

OXY USA Inc APD ATTACHMENT: SPUDDER RIG DATA

OPERATOR NAME / NUMBER: OXY USA Inc

1. SUMMARY OF REQUEST:

Oxy USA respectfully requests approval for the following operations for the surface hole in the drill plan:

1. Utilize a spudder rig to pre-set surface casing for time and cost savings.

2. Description of Operations

- 1. Spudder rig will move in to drill the surface hole and pre-set surface casing on the well.
 - **a.** After drilling the surface hole section, the spudder rig will run casing and cement following all of the applicable rules and regulations (OnShore Order 2, all COAs and NMOCD regulations).
 - **b.** The spudder rig will utilize fresh water-based mud to drill the surface hole to TD. Solids control will be handled entirely on a closed loop basis. No earth pits will be used.
- 2. The wellhead will be installed and tested as soon as the surface casing is cut off and the WOC time has been reached.
- 3. A blind flange at the same pressure rating as the wellhead will be installed to seal the wellbore. Pressure will be monitored with needle valves installed on two wingvalves.
 - a. A means for intervention will be maintained while the drilling rig is not over the well.
- 4. Spudder rig operations are expected to take 2-3 days per well on the pad.
- 5. The BLM will be contacted and notified 24 hours prior to commencing spudder rig operations.
- **6.** Drilling operations will begin with a larger rig and a BOP stack equal to or greater than the pressure rating that was permitted will be nippled up and tested on the wellhead before drilling operations resume on each well.
 - **a.** The larger rig will move back onto the location within 90 days from the point at which the wells are secured and the spudder rig is moved off location.
 - **b.** The BLM will be contacted / notified 24 hours before the larger rig moves back on the pre-set locations.
- 7. Oxy will have supervision on the rig to ensure compliance with all BLM and NMOCD regulations and to oversee operations.
- 8. Once the rig is removed, Oxy will secure the wellhead area by placing a guard rail around the cellar

Spudder Rig Layout Conex & Forklift Trailer Tool pusher