7	Sumit 1 Copy To Appropriate District Office	Energy, Minerals and Natural Resources Energy, Minerals and Natural Resources Energy, Minerals and Natural Resources OIL CONSERVATION DIVISION 1220 South St. Francis Dr.			Form C-103 Revised July 18, 2013			
	<u>District I</u> – (575) 393-6161							
	1625 N. French Dr., Hobbs, NM 88240				WELL API NO.			
					30-015-25576			
	District III – (505) 334-6178				5. Indicate Type			
	1000 Rio Brazos Rd., Aztec, NM 87410				STATE	FEE [
	<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 87505			6. State Oil & C	ias Lease No.		
	87505							
	SUNDRY NOTICES AND REPORTS ON WELLS				7. Lease Name	or Unit Agreemen	t Name	
1	(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A				}			
	DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)				Cornal Fl	7 Unit		
	1. Type of Well: Oil Well Gas Well Other				8. Well Number	: 1		
ŀ	2. Name of Operator				9. OGRID Num	han		
	OXY USA	9. OGKID Nulli	16696					
Ī	3. Address of Operator	10. Pool name o						
	P.O. Box 50250 Midland, TX 79710						. 201	
ŀ	4. Well Location	Corral Canyon	1 De laurane,	NW				
							_	
into thisicct from the							line	
ļ	Section 2			ange 29E , RKB, RT, GR, etc.	NMPM	County Edd	7	
				4.7				
Í	<u> </u>		3660	<u> </u>				
	•							
	12. Check	Appropriate Box to	o Indicate N	lature of Notice.	Report or Other	r Data		
					Troport of Other	. 12 444		
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CA							•	
	PERFORM REMEDIAL WORK	K 🗆	ALTERING CAS	SING □				
					ILLING OPNS.	P AND A		
	PULL OR ALTER CASING	MULTIPLE COMP	L 🗆	CASING/CEMEN	T JOB 🔲		_	
	DOWNHOLE COMMINGLE						•	
	CLOSED-LOOP SYSTEM	•						
_	OTHER:	<u> </u>		OTHER:				
	13. Describe proposed or comp	oleted operations. (Cl	early state all	pertinent details, an	d give pertinent dat	es, including estir	nated date	
	of starting any proposed w	of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of						
		proposed completion or recompletion.						
	TD-14002 PBTD-6	Hy OCD 24 hrs . prior to						
	13-3/9" 49# cca @ 6	677' w/ 700sx, 17-1/2" h	ala TOC surf c	··	cany weak each	ine.		
	9-5/8" 36# csg @ 3	112' w/ 2100sx, 17-1/2" ii 112' w/ 2100sx, 12-1/4"	hole, TOC-Surr-C	arc TC				
	7" 26# csg @ 10405							
7" 26# csg @ 10405' DVT @ 7017' w/ 1895sx, 8-3/4" hole, TOC-4010'-TS 4-1/2" 13.5# liner @ 10044-13985' w/ 460sx, 6-1/8" hole, TOC-10044'-Circ								
						RECEIVED		
1. RIH & set CIBP @ 5291', M&P 25sx cmt to 5191' - いのこもてag								
	2. Pèrf @ 3200', sq:)	MAY 1 7 2046	•				
	3. Perf @ 1855', sq		MAY 1 7 2019	j				
	4. Perf @ 727', sqz							
	5. Perf 7" & 9-5/8"	L. etc. 1	DIST	RICT <i>II-</i> ARTESIA (D.C. D.			
10# MLF between plugs - Above ground steel tanks will be utilized								
	,							
S	pud Date:		Rig Release Da	ite.				
Tog Release Date.								
_	See-Alla-k	COA	11	+101	()	<u> </u>		
	haraby contify that the information	1 473	7010	151 be 1 /4	sce by	<u>3/17/28</u>		
1,	hereby certify that the information	above is true and com	iplete to the be	est of my knowledge	e and belief.	,		
		/ /	-					
S	IGNATURE_		ΓΙΤLE Sr.	Dagulatana Adadaa	D.A. (T.)	وراجاره		
J	TONATORL Y 777	<u></u>	111LE <u>Sr.</u>	Regulatory Adviso	<u>r</u> DATI	E 5(15/19	_	
т	ype or print nameDavid Stewa	rt E	mail addrass.	david starrate	DIIO)	TE 422 605 67		
	JPC of print nameDavid Stewa	E-1	man auuress:	david_stewart@	voxy.com PHON	NE: <u>432-685-57</u>	1/	
F	or State Use Only	C						
-			-1	hx:		, ,		
Α	APPROVED BY:	May T	TILESTA -	F M.	DA	TE 5/17/19	7	
	Conditions of Approval (if any):	1		" '')' 	DA	TE VIII		
	• • • • • • • • • • • • • • • • • • • •							

OXY USA WTP LP - Proposed Corral Fly Unit #1 API No. 30-015-28576

150sx @ 200'-Surface

40sx @ 727-627' WOC-Tag

40sx @ 1855-1755' WOC-Tag

75sx @ 3200-3010' WOC-Tag

CIBP @ 5291' w/ 25sx to 5191'

CIBP @ 6180' w/ 35' cmt

CIBP @ 6950' w/ 35' cmt


CIBP @ 7850' w/ 35' cmt

CIBP @ 10000' w/ 35' cmt

CIBP @ 11398' w/ 35' cmt

CIBP @ 12700' w/ 35' cmt

CIBP @ 13275' w/ 35' cmt



OXY USA WTP LP - Current Corral Fly Unit #1 API No. 30-015-28576

17-1/2" hole @ 677' 13-3/8" csg @ 677' w/ 700sx-TOC-Surf-Circ

12-1/4" hole @ 3112' 9-5/8" csg @ 3112' w/ 2100sx-TOC-535'-TS

CIBP @ 6180' w/ 35' cmt

CIBP @ 6950' w/ 35' cmt

CIBP @ 7850' w/ 35' cmt

CIBP @ 10000' w/ 35' cmt

CIBP @ 11398' w/ 35' cmt

CIBP @ 12700' w/ 35' cmt

CIBP @ 13275' w/ 35' cmt

Perfs @ 5341-5366'

Perfs @ 6246-6424'

Perfs @ 7932-7942'

8-3/4" hole @ 10405' 7" csg @ 10405' w/ 1895sx-TOC-4010'-TS DVT @ 7017'

Perfs @ 11444-11768'

6-1/8" hole @ 14002' 4-1/2" liner @ 10044-13985' w/ 460sx-TOC-10044'-Circ´

Perfs @ 12754-12761

Perfs @ 13331-13553'

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)