Form 3160-5 (June 2015)

UNITED STATES FORM APPROVED

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT		Expires: January 31, 20 5. Lease Serial No.		
SUNDRY NOTICES AND REPORTS ON WELLS not use this form for proposals to drill or to re-enter an		NMNM117551		
demand well. Her form 2460 2 (ADD) for each present	•	6. If Indian, Allottee or Tribe Name		

Do not use this form for proposals to drill or to re-enter an				_			
Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.		6. If Indian, Allottee or Tribe Name					
SUBMIT IN TRIPLICATE - Other instructions on page 2		7. If Unit or CA/Agreement, Name and/or No.					
Type of Well ☐ Gas Well ☐ Other			8. Well Name and No. HEIGHT CC 6_7 FEDERAL COM 36H				
Name of Operator Contact: DAVID STEWART OXY USA INCORPORATED E-Mail: david_stewart@oxy.com			9. API Well No. 30-015-45564-00-X1				
3a. Address 5 GREENWAY PLAZA SUITE 110 HOUSTON, TX 77046-0521 3b. Phone No. (include area code) Ph: 432.685.5717			10. Field and Pool or Exploratory Area PURPLE SAGE-WOLFCAMP (GAS)				
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)			11. County or Parish, State				
Sec 6 T24S R29E 65FNL 1006FEL 32.254025 N Lat, 104.018494 W Lon			EDDY COUNTY, NM				
12. CHECK THE AF	PPROPRIATE BOX(ES) TO INDI	CATE NATURE O	F NOTICE,	REPORT, OR OTH	IER D	OATA	
TYPE OF SUBMISSION	TYPE OF ACTION						
Notice of Intent ■ Notice of Intent	☐ Acidize ☐	Deepen	☐ Producti	on (Start/Resume)	υŅ	Vater Shut-Off	
	☐ Alter Casing ☐ Hydraulic Fracturing ☐		☐ Reclama	ation -		Vell Integrity	
☐ Subsequent Report	☐ Casing Repair ☐	New Construction	☐ Recomp	lete		Other	
Final Abandonment Notice	☐ Change Plans ☐	Plug and Abandon	▼ Tempora	rarily Abandon			
	☐ Convert to Injection ☐	Plug Back	■ Water D	ater Disposal			
Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection. OXY USA Inc. respectfully request to TA this well. While drilling the lateral production hole @ 17973', the well took a frac hit. OXY proposes the following procedure to TA the well with plans to return in the fall of 2019 after the current wells have been completed. 1. RU WL & set RBP @ 8972', pressure test to 1000# for 10min. to ensure proper seal. RIH & circ hole w/ 10# brine, POOH. 2. RU WL & RIH & set RBP @ 8772', pressure test to 1000# for 30min. Carlsbad Field Office 3. RU WL & RIH & set RBP @ 3000', perform negative pressure test by shutting down for the file of the foregoing is true and correct.							
Com	Electronic Submission #469731 ve For OXY USA INCORP Imitted to AFMSS for processing by	ORATED, sent to the PRISCILLA PEREZ or	Carlsbad n 06/19/2019	(19PP2514SE)			
Name (Printed/Typed) DAVID ST	EWART	Title REGUL	Title REGULATORY ADVISOR				
Signature (Electronic S	Submission)	Date 06/19/20	Date 06/19/2019				
	THIS SPACE FOR FEDE	RAL OR STATE (OFFICE US	SE			
Approved By NDUNGU KAMAU Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		se Office Carlsbac	d			Date 07/16/2019	
Title 18 U.S.C. Section 1001 and Title 43 States any false, fictitious or fraudulent s	U.S.C. Section 1212, make it a crime for a statements or representations as to any materials.	ny person knowingly and ter within its jurisdiction	willfully to ma	ke to any department or	agency	of the United	

Additional data for EC transaction #469731 that would not fit on the form

32. Additional remarks, continued

4. ND, install nightcap w/ pressure gauge to monitor well. Skid well.

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Conditions of Approval for Temporary Abandonment of Wells

Definition: A temporarily abandoned well is a completion that is not capable of production in paying quantities but which may have future value. Pursuant to 43 CFR 3162.3-4 (c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Note: TA status "will be effective for a period up to 1 year from the date of NOI approval and can be renewed annually thereafter" per IM NM-2016-017.

- A bridge plug (CIBP) must be installed 50 to 100 feet above any open perforations or open hole. The CIBP must be capped with either a minimum of 25 sacks of cement if placed with tubing or 35 feet of cement if placed with a bailer. The top of the cement must be verified by tagging.
- 2. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes. If the well does not pass the casing integrity test, then the operator shall, within 30 days, submit a procedure to either repair the casing or to plug and abandon the well.
- 3. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County, 575-361-2822; Lea County 575-393-3612.
- 4. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if it is not isolated by a packer.
- 5. A bradenhead test must be conducted. If the test indicates a problem, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
- 6. Submit a subsequent Sundry Notice (Form 3160-5) with the following information:
 - a. A well bore diagram with all perforations, CIBP's, and tops of cement on CIBP's.
 - b. A description of the temporary abandonment procedure.
 - c. A clear copy or the original of the pressure test chart.