

Submit 1 Copy To Appropriate District Office  
District I - (575) 393-6161  
1625 N. French Dr., Hobbs, NM 88240  
District II - (575) 748-1283  
811 S. First St., Artesia, NM 88210  
District III - (505) 334-6178  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV - (505) 476-3460  
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised July 18, 2013

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-005-63402
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. VO-5583
7. Lease Name or Unit Agreement Name Casino AXC State
8. Well Number 2
9. OGRID Number 7377
10. Pool name or Wildcat Foor Ranch; Wolfcamp Gas
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3,899' GR

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other	
2. Name of Operator EOG Resources, Inc.	
3. Address of Operator 104 South Fourth Street, Artesia, NM 88210	
4. Well Location Unit Letter <u>P</u> : <u>660</u> feet from the <u>South</u> line and <u>810</u> feet from the <u>East</u> line Section <u>2</u> Township <u>10S</u> Range <u>26E</u> NMPM <u>Chaves</u> County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3,899' GR	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

**Notify OCD 24 hrs. prior to any work done.**

1. MIRU all safety equipment as needed. NU BOP. POOH with production equipment.  
2. Set CIBP at 5632 ft with 35 ft of CLS C on top. - WOC & Tag  
3. Spot a 25 SX (362 ft) CLS C cement plug 5022 ft - 5384 ft. WOC & Tag Plug. This will plug the Wolfcamp.  
4. Perforate at 4704 ft. Attempt to establish Circulation or spot I/O. Requires 40 SX (147 ft) CLS C cement plug 4557 ft - 4704 ft. WOC & Tag Plug. This will plug the Abo  
5. Perforate at 3935 ft. Attempt to establish Circulation or spot I/O. Requires 38 SX (139 ft) CLS C cement plug 3796 ft - 3935 ft. WOC & Tag Plug. This will plug the Tubb  
6. Perforate at 2522 ft. Attempt to establish Circulation or spot I/O. Requires 65 SX (241 ft) CLS C cement plug 2281 ft - 2522 ft. WOC & Tag Plug. This will plug the Yeso/Glorieta *Perf @ 1157 - shoe*  
7. Perforate at 1308 ft. Attempt to establish Circulation or spot I/O. Requires 162 SX (596 ft) CLS C cement plug 712 ft - 1308 ft. WOC & Tag Plug. This will plug the San Andres, Grayburg, & Shoe  
8. Perforate at 712 ft. Attempt to establish Circulation or spot I/O. Requires 131 SX (107 ft) CLS C cement plug 306 ft - 712 ft. WOC & Tag Plug. This will plug the Queen & 7 Rivers  
9. Perforate at 310 ft. Attempt to establish Circulation or spot I/O. Requires 28 SX (103 ft) CLS C cement plug 207 ft - 310 ft. WOC & Tag Plug. This will plug the Yates  
10. Spot a 10 SX (145 ft) CLS C cement plug 0 ft - 145 ft. WOC & Tag Plug. This will plug the Top.  
Cut off wellhead and weld on dry hole marker. Clean location as per regulation.

Spud Date:  Rig Release:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jeremy Haass TITLE Regulatory Specialist DATE November 22, 2019

Type or print name Jeremy Haass E-mail address: jeremy\_haass@eogresources.com PHONE: 575-748-4311

For State Use Only

APPROVED BY: [Signature] TITLE Staff mg. DATE 11/27/19


Conditions of Approval (if any):

# Casino AXC St #2

Sec-TWN-RNG: Sec. 2-T10S-R26E  
FOOTAGES: 660' FSL & 810' FEL  
CURRENT

API: 30-005-63402  
GL: 3,899'  
KB:

COMMENTS



## CASING DETAIL

#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Cmt	Circ/TOC	TOC Method
B	12 1/4"	8 5/8"	24.4	J-55	0	1,107'	780		
C	7 7/8"	4 1/2"	11.6#	J-55	0	6,266'	1120	4,000'	CBL

## FORMATION TOPS

Formation	Estimated Top	other
Devonian	6,166'	x
Mississippian	6,109'	x
Strawn	5,966'	x
Cisco	5,859'	x
Spear	5,668'	x
B zone	5,428'	
Wolfcamp	5,334'	
Abo	4,654'	4000 toc
Tubb	3,885'	
Yeso	2,472'	
Glorieta	2,355'	
San Andres	1,258'	1107 Shoe
Grayburg	1,024'	
Queen	737'	
7 Rivers	360'	
Yates	260'	

## Plugs

Set CIBP at 5632 ft with 35 ft of CLS C on top.

Spot a 25 SX (362 ft) CLS C cement plug 5022 ft - 5384 ft. WOC & Tag Plug. This will plug the Wolfcamp.

Perforate at 4704 ft. Attempt to establish Circulation or spot I/O. Requires 40 SX (147 ft) CLS C cement plug 4557 ft - 4704 ft. WOC & Tag Plug. This will plug the Abo

Perforate at 3935 ft. Attempt to establish Circulation or spot I/O. Requires 38 SX (139 ft) CLS C cement plug 3796 ft - 3935 ft. WOC & Tag Plug. This will plug the Tubb

Perforate at 2522 ft. Attempt to establish Circulation or spot I/O. Requires 65 SX (241 ft) CLS C cement plug 2281 ft - 2522 ft. WOC & Tag Plug. This will plug the Yeso/Glorieta

Perforate at 1308 ft. Attempt to establish Circulation or spot I/O. Requires 162 SX (596 ft) CLS C cement plug 712 ft - 1308 ft. WOC & Tag Plug. This will plug the San Andres, Grayburg, & Shoe

Perforate at 712 ft. Attempt to establish Circulation or spot I/O. Requires 131 SX (107 ft) CLS C cement plug 306 ft - 712 ft. WOC & Tag Plug. This will plug the Queen & 7 Rivers

Perforate at 310 ft. Attempt to establish Circulation or spot I/O. Requires 28 SX (103 ft) CLS C cement plug 207 ft - 310 ft. WOC & Tag Plug. This will plug the Yates

Spot a 10 SX (145 ft) CLS C cement plug 0 ft - 145 ft. WOC & Tag Plug. This will plug the Top.

TOC (good cement) @ 4000'


Packer @ 5388'

Perfed Wolfcamp @  
5682-5688' 24 holes

PBTD: 6,220' MD  
TD: 6,266' MD

**Casino AXC St #2**

COMMENTS	
	TOC (good cement) @ 4000'
	Packer @ 5388'
	Perfed Wolfcamp @ 5682'-5688' 24 holes



Sec-TWN-RNG:	Sec. 2-T10S-R26E	API:
FOOTAGES:	660' FSL & 810' FEL	GL:
CURRENT		KB:

30-005-63402  
3,899'

[illegible]

	Formation	Estimated Top						
	Yates	260'						
	7 Rivers	360'						
	Queen	737'						
	Grayburg	1,024'						
	San Andres	1,258'						
	Glorieta	2,355'						
	Yeso	2,472'						
	Tubb	3,885'						
	Abo	4,654'						
	Wolfcamp	5,334'						
	B zone	5,428'						
	Spear	5,668'						
	Cisco	5,859'						
	Strawn	5,966'						
	Mississippian	6,109'						
	Devonian	6,166'						

[illegible][illegible]


## **CONDITIONS FOR PLUGGING AND ABANDONMENT**

### **OCD - Southern District**

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water will not be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

#### **DRY HOLE MARKER REQUIREMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least 1/4" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter  
 Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date  
 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)