

Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT ARTESIAO.C.D.
SUNDRY NOTICES AND REPORTS ON WELLS

FORM APPROVED OMB No. 1004-0137 Expires: January 31, 2018

		-
5. Lease Serial	No. 1 C-029	115_B

6. If Indian, Allottee or Tribe Name

	form for proposals to d Use Form 3160-3 (APD)		-		
SUBMIT IN	TRIPLICATE - Other instruction	7. If Unit of CA/A	7. If Unit of CA/Agreement, Name and/or No.		
1. Type of Well					
✓ Oil Well Gas V		8. Well Name and	No. PUCKETT B 003		
2. Name of Operator HUDSON OIL C		9. API Well No.	-015-05377		
OTO TEXT OF OTTEET		Phone No. (include area code		10. Field and Pool or Exploratory Area	
FORT WORTH, TX 76		7) 336-7109	MALJAMAR		
4. Location of Well (Footage, Sec., T., I S24; T17S; R31E; 660 SOUTH A		11. Country or Par EDDY, NEW M	,		
	CK THE APPROPRIATE BOX(E	SOLTO INDICATE NATURE			
TYPE OF SUBMISSION	CR THE ATTROFICIATE BOX(E			OTHER DATA	
TIPE OF SUBMISSION	(manufa)	-	PE OF ACTION		
✓ Notice of Intent	Acidize Alter Casing	Deepen Hydraulic Fracturing	Production (Start/Resun	ne)	
Subsequent Report	Casing Repair	New Construction	Recomplete	Other /20/19MOCD	
	Change Plans	✓ Plug and Abandon	Temporarily Abandon	Accepted for record NIMOCD	
Final Abandonment Notice	Convert to Injection	Plug Back	Water Disposal	Accepted Work and approximate duration thereof. If	
stand back in derrick.	with tubing and tag CIBP. Test of RIH with tbg and tag cement @ eeze holes @ 2,000'. Squeeze @ 740'. Squeeze cement acr 1/4" casing @ 60'. Squeeze 5 cement to surface around both	casing to 500 psi. Displace 2,780'. If necessary, pure ecement plug from 2,000'- ross 8-1/4" shoe from 240' 0 sx cement to surface.	e well with 9.5 ppg mud. Snp additional cement to bring 17/0 -1,750. WOC. RIH and to 5.500. SEE ATT ow ground dry hole marker	cement. POOH with tubing.	
RECLAMATIO	N: "Rip and remove ca	liche, contour to su	rrounding topograp	hy, reseed." ENTERED	
14. I hereby certify that the foregoing is KAREN ZORNES	true and correct. Name (Printed/	* * *	ORY CONSULTANT	IN AFMSS Dm 19/2	
Signature Janen	mus	Date	10/1	5/2019	
	THE SPACE FO	R FEDERAL OR ST	ATE OFICE USE		
Approved by Conditions of approved figure and a state certify that the applicant holds legal or	hed. Approval of this notice does requitable title to those rights in the	Title not warrant or e subject lease Office	SIET	Date 11-3-19	

Title 8 U.S. Section 1001 and Title 43 U.S.C Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States

(Instructions on page 2)

which would entitle the applicant to conduct operations thereon.

any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

<u>Hudson Oil of Texas – P&A Procedure – 10/14/2019</u>

Puckett "B" #3

API #: 35-015-05377

AFE#:

Field: Maljamar-GB-SA

Surf Location: Sec 24, T17S - R31E

660' FSL & 1980' FEL

Latitude: 00.0000° N / Longitude: -00.0000° W

Eddy County, NM Spud Date: 5-20-41

Directions to Location

From Maljamar: West on Hwy 82 for 4 miles. Turn south into location.

Description	Size	Wght	Grade	ID	Drift	Burst	Collapse	Btm MD	TOC
Surface	8-1/4"	28		8.097"	7.972"			610'	
Production	7"	20		4.95"	4.825"			3,316'	1,552' Est
Tubing	2-3/8"	4.7	J-55	2.441"	2.347"	7,260	7,680	2,969'	

KB: 3,904' **GL**: 3,893' **PBTD**: 3,944' **TD**: 3,951'

Current Perfs: 3,316' - 3,944' Open Hole

Objective: P&A Well Bore in compliance with the rules and regulations for the state of New Mexico.

Proposed Perfs: N

Attempt to est. inj. late below Top fish. If can set CR and SOZ Vol of hole from 3000'-TD. Procedure All out Cap CR 10/25 5x ent.

- 1. MIRU well service rig and plugging equipment. POOH and lay down rods. RD pumping tee and install 7-1/6" 3K BOP's. Strap tubing out of hole and stand back in derrick.
- 2. Set CIBP @ 3,030'. RIH with tubing and tag CIBP. Test casing to 500 psi. Displace well with 9.5 ppg mud. Spot 65 sx cement on top of CIBP. POOH with tubing and WOC. RIH with tbg and tag cement @ 2,780'. If necessary, pump additional cement to bring top to 2,780'.
- 3. POOH with tbg. Shoot squeeze holes @ 2,000'. Squeeze cement plug from 2,000' 1,750'. WOC. RIH and tag cement. POOH.

4. RIH and perforate 7" casing @ 210'. Squeeze cement across 8-1/4" shoe from 710' - 500'. WOC. RIH and tag cement. POOH with tubing.

- 5. RIH and perforate 7" and 8-1/4" casing @ 60'. Squeeze 50 sx cement to surface.
- 6. Cut off well head and verify cement to surface around both casing strings. Install below ground dry hole marker.
- 7. Cut off anchors, Rip and remove caliche, contour to surrounding topography. and reseed location.

THIS PROCEDURE HAS BEEN PROPOSED IN CONSIDERATION OF AND WITH RESPECT GIVEN TO THE MANY VARIABLES AND POTENTIAL PROBLEMS THAT MAY BE ENCOUNTERED IN THIS WELL IN THIS GEOGRAPHICAL AREA. THEREFORE, THIS PROCEDURE IS TO SERVE AS A GENERAL GUIDELINE AND WILL BE REVIEWED AND MODIFIED WHEN REQUIRED AS DETERMINED BY ACTUAL WELLBORE CONDITIONS ENCOUNTERED IN THE OPERATIONS. SAFETY AND PRUDENT PRACTICES WILL TAKE PRIORITY AT ALL TIMES.

Notify BLM Prior to any changes in Approval.


Prior to rig up of any operations and prior to the actual operations, always hold safety meeting to discuss any potential hazards, accurately record names of all personnel on location, pick meeting place, discuss evacuation plans, designate hospital of choice and have coordinates and phone numbers for care flight operations if necessary. Completely discuss the operation and/or rig-up so that all personnel understand the plan, responsibilities and any potential changes that may take place during the rig up or operation


Prepared By:

Greg Milner

Date: 10-14-19

Petroleum Engineer





- 1		
	Date:	10/14/2019
	By:	Greg Milner

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval (LPC Habitat)

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of brine water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Below Ground Level Cap (Lesser Prairie-Chicken Habitat): All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off. Upon the plugging and subsequent abandonment of wells that are located in lesser prairie-chicken habitat, the casings shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The well bore shall then be covered with a metal plate at least ¼ inch thick and welded in place. A weep hole shall be left in the plate and/or casing.

NMOCD also requires the operator to notify NMOCD when this type of dry hole marker is used. This can be done on the subsequent report of abandonment which is submitted to the BLM after the well is plugged. State that a below ground cap was installed as required in the COA's from the BLM.

- 7. Subsequent Plugging Reporting: Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.

<u>Tinuing Limitation Stipulation/ Condition of Approval for Lesser Prairie-Chicken:</u>
From March 1st through June 15th annually, abandonment activities will be allowed except between the hours from 3:00 am and 9:00 am. Normal vehicle use on existing roads will not be restricted