Submit 3 Copies To Appropriate District	State of New Mexico	Form C-103
Office District I •	Energy, Minerals and Natural Resources	June 19, 2008
1625 N. French Dr., Hobbs, NM 88240	Mar of the	WELL API NO.
<u>District II</u> 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION	30-015-36305
District III	1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe, NM 87505	STATE FEE FEE
<u>District IV</u> 1220 S. St. Francis Dr., Santa Fe, NM	Banta 1 C, 14141 07505	6. State Oil & Gas Lease No.
87505		VO-0883
	ICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPO	OSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A CATION FOR PERMIT" (FORM C-101) FOR SUCH	Stogey BLG State Com
PROPOSALS.)	CATION FOR FERMIT (FORM C-101) FOR SOCH	8. Well Number
1. Type of Well: Oil Well	Gas Well Other	1H
2. Name of Operator	SEP -8 2008	9. OGRID Number
Yates Petroleum Corporation	· · ·	025575
3. Address of Operator	OCD-ARTES	10. Pool name or Wildcat
105 South Fourth Street, Artesia, N	NM 88210	Willow Lake; Bone Spring
4. Well Location		
Unit Letter A :	660 feet from the North line and	660 feet from the East line
Unit Letter D` :	660 feet from the North line and	330 feet from the line
Section 36	Township 24S Range 27E	NMPM Eddy County
	11. Elevation (Show whether DR, RKB, RT, GR,	etc.)
	3079'GR	
12. Check	Appropriate Box to Indicate Nature of Notice	e, Report or Other Data
NOTICE OF IN	ITENTION TO	IDOCOLICAT DEDOCT OF
		JBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON REMEDIAL W	_
TEMPORARILY ABANDON DULL OR ALTER CASING		DRILLING OPNS. P AND A
DOWNHOLE COMMINGLE	WIDETIFLE COMPL CASING/CEM	ENT JOB
DOMINIOEE COMMININGEE		
OTHER:	OTHER: 7" ca	sing 🖂
OTHER: 13. Describe proposed or comp	OTHER: 7" capleted operations. (Clearly state all pertinent details	
13. Describe proposed or comp of starting any proposed we		and give pertinent dates, including estimated date
13. Describe proposed or comp	pleted operations. (Clearly state all pertinent details	and give pertinent dates, including estimated date
13. Describe proposed or comp of starting any proposed we or recompletion.	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion
13. Describe proposed or composed we or recompletion. 8/18/08 – Set kickoff plug at 8050'	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1st squeeze plug at 41	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 7'-4040' – 55 sx of 13#. Squeezed cement from
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050's 4117'-4040'. Set 2 nd squeeze plug at	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050's 4117'-4040'. Set 2 nd squeeze plug at 8/20/08 – Drilling cement plugs. W	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement complete the state of the state	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050's 4117'-4040'. Set 2 nd squeeze plug at 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement f	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 'OC. Tagged at 3050'. Solid plug – good cement cofrom 3446'-3775'. Drilled cement from 4040'-4114	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 2'. TIH to kickoff plug and tagged up at 7500'.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement for Drilled cement from 7500'-7640'.	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement co from 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 2'. TIH to kickoff plug and tagged up at 7500'. 3'.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050's 4117'-4040'. Set 2 nd squeeze plug at 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. If 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 'OC. Tagged at 3050'. Solid plug – good cement cofrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. Imming back over shakers. Drilled cement plug 1.8'. TIH to kickoff plug and tagged up at 7500'. 3'. 1.9' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement cofrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 2'. TIH to kickoff plug and tagged up at 7500'. 3'. 10 + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement to 7835' which is KOP.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 'OC. Tagged at 3050'. Solid plug – good cement cofrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 2'. TIH to kickoff plug and tagged up at 7500'. 3'. 10 + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement to 7835' which is KOP.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement cofrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 2'. TIH to kickoff plug and tagged up at 7500'. 3'. 10 + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement to 7835' which is KOP.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole Spud Date:	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down Rig Release Date:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 2'. TIH to kickoff plug and tagged up at 7500'. 3'. 10 + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement to 7835' which is KOP.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement cofrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 2'. TIH to kickoff plug and tagged up at 7500'. 3'. 10 + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement to 7835' which is KOP.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole Spud Date:	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement confrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 at to 6-1/8" and resumed drilling. Drilled plug down Rig Release Date: Rig Release Date: Rig Release Date: Rig Release Date:	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 1.7'-4040' - 55 sx of 13#. Squeezed cement from at 3150'-2970' - 90 sx of 13#. ming back over shakers. Drilled cement plug and tagged up at 7500'. 3'. 1. TIH to kickoff plug and tagged up at 7500'. 3'. 1. + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement o 7835' which is KOP.
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug a 8/20/08 – Drilling cement plugs. W from 3302'-3446'. Drilled cement from 7500'-7640'. I 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in v circulated to surface. Reduced hole Spud Date:	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down Rig Release Date: Rig Release Date: TITLE Regulatory Compliance above is true and complete to the best of my known.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug and tagged up at 7500'. 3'. 1' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement o 7835' which is KOP. 1 **Experimental Lates of the September 4, 2008 2 **Experimental Lates of the September 4, 2008 3 **Experimental Lates of the September 4, 2008 4 **Experimental Lates of the September 4, 2008 5 **Experimental Lates of the September 4, 2008 5 **Experimental Lates of the September 4, 2008 6 **Experimental Lates of the September 4, 2008 6 **Experimental Lates of the September 4, 2008 6 **Experimental Lates of the September 4, 2008 1 **Experimental Lates of the September 4, 2008 1 **Experimental Lates of the September 4, 2008 1 **Experimental Lates o
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug at 8/20/08 – Drilling cement plugs. We from 3302'-3446'. Drilled cement from 7500'-7640'. If 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in vecirculated to surface. Reduced hole Spud Date: I hereby certify that the information SIGNATURE Type or print name Tina Hue	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug (OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 (Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 (with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 (to 6-1/8") and resumed drilling. Drilled plug down Rig Release Date: Rig Release Date: TITLE Regulatory Compliance (Proposition of the Proposition of the Pr	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug 1. TIH to kickoff plug and tagged up at 7500'. 13'. 10 + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% 14 + 0.2% D167 (yld 1.40, wt 13). Cement of 7835' which is KOP. 18 EPTED POR RECORD 2 Supervisor 20 BATE September 4, 2008 19 GPH OF Puty Field Inspector CD-District II ARTESIA
13. Describe proposed or compof starting any proposed we or recompletion. 8/18/08 – Set kickoff plug at 8050' 4117'-4040'. Set 2 nd squeeze plug at 8/20/08 – Drilling cement plugs. We from 3302'-3446'. Drilled cement from 7500'-7640'. If 8/24/08 – Set 7" 26# casing at 7753 D167 (yld 3.19, wt 9.9). Tailed in vecirculated to surface. Reduced hole Spud Date: I hereby certify that the information SIGNATURE Type or print name Tina Hue	pleted operations. (Clearly state all pertinent details ork). SEE RULE 1103. For Multiple Completions: to 7600' – 230 sx of 17#. Set 1 st squeeze plug at 41 at 3516'-3390' – 70 sx of 13#. Set 3 rd squeeze plug 7OC. Tagged at 3050'. Solid plug – good cement coffrom 3446'-3775'. Drilled cement from 4040'-4114 Kick off plug good and solid. Drilled cement to 775'. Cemented with 415 sx Litecrete + 0.125#/sx D13 with 80 sx PVL + 1% D44 + 0.1% D13 + 0.2% D65 to 6-1/8" and resumed drilling. Drilled plug down Rig Release Date: Rig Release Date: TITLE Regulatory Compliance above is true and complete to the best of my known.	and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion 17'-4040' – 55 sx of 13#. Squeezed cement from at 3150'-2970' – 90 sx of 13#. ming back over shakers. Drilled cement plug and tagged up at 7500'. 3'. 1' + 2#/sx LCM + 0.2% D46 + 1% D153 + 0.3% + 0.2% D167 (yld 1.40, wt 13). Cement o 7835' which is KOP. 1 **Experimental Lates of the September 4, 2008 2 **Experimental Lates of the September 4, 2008 3 **Experimental Lates of the September 4, 2008 4 **Experimental Lates of the September 4, 2008 5 **Experimental Lates of the September 4, 2008 5 **Experimental Lates of the September 4, 2008 6 **Experimental Lates of the September 4, 2008 6 **Experimental Lates of the September 4, 2008 6 **Experimental Lates of the September 4, 2008 1 **Experimental Lates of the September 4, 2008 1 **Experimental Lates of the September 4, 2008 1 **Experimental Lates o