

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
June 19, 2008

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505



SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-015-26040
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Read & Stevens, Inc.		6. State Oil & Gas Lease No. V-2293
3. Address of Operator P. O. Box 1518, Roswell, NM 88202-1518		7. Lease Name or Unit Agreement Name Marbob State
4. Well Location Unit Letter: A 660 feet from the North line and 660 feet from the East line Section: 19 Township: 19S Range: 29E NMPM County: Eddy		8. Well Number 1
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3,358' GR		9. OGRID Number 18947
		10. Pool name or Wildcat Scanlon Draw Bone Springs

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work): SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Read & Stevens to move in before plugging crew and pull rods & tubing.
2. Set CIBP, inside of 5 1/2" casing, @ 1375' (above Queen perms from 1444-58 & 1986-96) with 75' of cement.
3. Set 100' Cement Plug from 325' to 425'. - TAG
4. Cut off wellhead and set 60' surface plug.
5. Install dryhole marker
6. Reclaim surface per OCD recommendation.

**Notify OCD 24 hrs. prior
To any work done.**

Note: Exhibit A = Current wellbore, Exhibit B = Proposed PA wellbore

Spud Date: 02/03/89

Rig Release Date: 03/28/89

Approval Granted providing work
is complete by 3/9/08

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE: David Luna TITLE: Petroleum Engineer

DATE: 12/04/2008

Type or print name: David Luna
213

E-mail address: dluna@read-stevens.com

PHONE: 575-622-3770 ext.


For State Use Only

APPROVED BY: PhD Huffer TITLE: CO

DATE: 12/9/08


Conditions of Approval (if any):

Marbob State #1
Read Stevens, Inc.
Eddy Co., NM
660'FNL 660'FEL
Sec. 19, T19S-R29E
API: 30-015-26040
Field: Turkey Track (Queen)
Exhibit A: Current Wellbore



i-Handbook* - *a mark of Schlumberger

Marbob State #1
Read Stevens, Inc.
Eddy Co., NM
660'FNL 660'FEL
Sec. 19, T19S-R29E
API: 30-015-26040
Field: Turkey Track (Queen)
Exhibit B: Proposed PA Wellbore



i-Handbook* - *a mark of Schlumberger