

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

AUG 17 2009

Form C-103
June 19, 2008

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-24732
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E30363
7. Lease Name or Unit Agreement Name Theos State
8. Well Number 1
9. OGRID Number
10. Pool name or Wildcat Grayburg, Jackson, SA,

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>
2. Name of Operator Marks & Garner Production LTD., CO
3. Address of Operator P.O. Box 108
4. Well Location Unit Letter G : 1650 feet from the NORTH line and 1650 feet from the EAST line Section 05 Township 17S Range 29E NMPM EDDY County
11. Elevation (Show whether DR, RKB, RT, GR, etc.)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
DOWNHOLE COMMINGLE <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- 12-28-08
1. Move in unit & rig up.
 2. Run guage ring to 2500'
 3. Set CIBP @ 2400'
 4. Dump 35' cement on CIBP
 5. pick up approx. 2350' tbg, & run in the hole
 6. Circulate hole with mud gel
 7. Come out of hole with tbg & lay down
 8. set CIBP @ 1600'
 9. Dump 35' cement on CIBP
 10. spot 100' plug @ surface
 11. Rig down unit

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Quinn Borsini TITLE Manager DATE 8-15-09
Type or print name Quinn Borsini E-mail address: Quinn.Borsini@state.nm.us PHONE: 505-393-9388
For State Use Only
APPROVED BY: Adrian Hawke TITLE Manager DATE 8/18/09
Conditions of Approval (if any):

Approved for plugging of well bore only
Liability under bond is retained pending receipt
of C-103 (Subsequent Report of Well Plugging)
which may be found at OCD Web Page under
Forms, www.emnrd.state.nm.us/oed.