Submit 1 Copy To Appropriate District Office State of	New Mexico	Form C-103
<u>District I</u> Energy, Minerals and Natural Resources October 13, 200		October 13, 2009
1625 N French Dr , Hobbs, NM 88240	_b.1a	WELL API NO.
District II 1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION		30-005-61202
District III 1220 South St. Francis Dr.		5. Indicate Type of Lease STATE FEE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV Santa Fe, NM 87505		6. State Oil & Gas Lease No.
1220 S St. Francis Dr., Santa Fe, NM	,	18489
87505	NI WELL C	<u> </u>
SUNDRY NOTICES AND REPORTS ON WELLS  (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  PROPOSALS.)		7. Lease Name or Unit Agreement Name Wagner-SCR-272
1. Type of Well: Oil Well Gas Well Other	RECEIVED	8. Well Number 1
2. Name of Operator		9. OGRID Number
The Eastland Oil Company	OCT <b>26</b> 2009	022767
3. Address of Operator	A DTECIA	10. Pool name or Wildcat
P. O. Box 3488 Midland TX 79702	NMOCD ARTESIA	Pecos Slope Abo
4. Well Location		
Unit Letter N : 1980 feet from the West line and 660 feet from the South line		
Section 10 Township 7	-S Range 26E	NMPM County Chaves
	hether DR, RKB, RT, GR, etc.,	
3715 GR	,	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data		
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:		
PERFORM REMEDIAL WORK PLUG AND ABANDON		
TEMPORARILY ABANDON	COMMENCE DRI	LLING OPNS. PANDA
PULL OR ALTER CASING MULTIPLE COMPL	<del>_</del>	TJOB
DOWNHOLE COMMINGLE		Assistant and the second of th
	_	
OTHER:		
13. Describe proposed or completed operations. (Clear	ly state all pertinent details, and	
13. Describe proposed or completed operations. (Clear of starting any proposed work). SEE RULE 19.15.7	ly state all pertinent details, and 7.14 NMAC. For Multiple Cor	npletions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we	ly state all pertinent details, and 7.14 NMAC. For Multiple Cor	npletions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.	ly state all pertinent details, and 7.14 NMAC. For Multiple Cor	npletions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer	ly state all pertinent details, and 7.14 NMAC. For Multiple Cor	npletions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag	ly state all pertinent details, and 7.14 NMAC. For Multiple Cor	npletions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid.	ly state all pertinent details, and 7.14 NMAC. For Multiple Cor	npletions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag	ly state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 3/4" set @ 965' with ceme	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag.	ly state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 3/4" set @ 965' with ceme	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface.	ly state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 3/4" set @ 965' with ceme	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag.	ly state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 3/4" set @ 965' with ceme	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restore	ly state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 3/4" set @ 965' with ceme	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restore	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cements.	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restore	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cements.	npletions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restore	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cements.	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restore	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cements.	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta  6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 12/2/2.	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cemely generally and the corolling.	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta  6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 1.2.	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cements.	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta  6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 12/2/2.	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cemely generally and the corolling.	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta  6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 12/2/2.	ly state all pertinent details, and 7.14 NMAC. For Multiple Coroll: 10 3/4" set @ 965' with cemely generally and the corolling.	npletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta  6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 12/2/2.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 3/4" set @ 965' with cemeral set.	inpletions: Attach wellbore diagram of ent circulated to surface. 4 ½" 9.5# set @  Only Work done.
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restored providing is complete by 12/2.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 ¾" set @ 965' with cemel location.	e and belief.
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restored providing is complete by 1.2.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 ¾" set @ 965' with cemel location.	e and belief.
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer 2) Spot 30 sk. Plug @ 4382' across perfs: & tag 3) Load hole w/mud laden fluid. 4) Check free point on casing. Cut & pull. 5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag. 7) Spot 10 sk plug @ surface. 8) Set dry hole marker, remove equipment & restored providing is complete by 12/2.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 ¾" set @ 965' with cemel location.	e and belief.
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 1.2/2'.  Spud Date:  Rig  I hereby certify that the information above is true and complete by 1.2/2'.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 ¾" set @ 965' with cemel location.  Release Date:  Agent	e and belief.  DATE 10. 22-09
13. Describe proposed or completed operations. (Clear of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 12/2  Spud Date:  Rig  Type or print name Travis Reed E-material providing is complete.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 ¾" set @ 965' with cemel location.  Release Date:  Agent	e and belief.
of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 1.2/2'.  Spud Date:  Rig  I hereby certify that the information above is true and complete by 1.2/2'.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 ¾" set @ 965' with cemel location.  Release Date:  Agent	phone: _432-683-6293
13. Describe proposed or completed operations. (Clear of starting any proposed work). SEE RULE 19.15.7 proposed completion or recompletion. Casing in we 4801' cement w/450 sks. Did not circulate.  1) Pull tubing & Packer  2) Spot 30 sk. Plug @ 4382' across perfs: & tag  3) Load hole w/mud laden fluid.  4) Check free point on casing. Cut & pull.  5) Spot 35 sk plug across stub. 50' in & 50' out & ta 6) Spot 25 sk plug 1015' across surface pipe & tag.  7) Spot 10 sk plug @ surface.  8) Set dry hole marker, remove equipment & restored is complete by 12/2  Spud Date:  Rig  Type or print name Travis Reed E-material providing is complete.	y state all pertinent details, and 7.14 NMAC. For Multiple Corll: 10 3/4" set @ 965' with cemel lice to the best of my knowledge that the best of my knowledge and address:	e and belief.  DATE 10. 22-09