

OCD-ARTESIA

RECEIVED

APR 12 2010

NMOCD ARTESIA

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

FORM APPROVED

OMB No 1004-0137

Expires July 31, 2010

SUBMIT IN TRIPLICATE - Other Instructions on page 2.

1 Type of Well



Oil Well



Gas Well



Other

2 Name of Operator

Marbob Energy Corporation

3a Address

PO Box 227
Artesia, NM 88211-0227

3b Phone No (include area code)

(575) 748-3303

4 Location of Well (1-outage, Sec., T., R., M., or Survey Description)

1980 FNL 660 FEL, Sec. 23-T17S-R29E, Unit H

5 Lease Serial No

NMLC028784B

6 If Indian, Allottee, or Tribe Name

7 If Unit or CA Agreement Name and/or No

NMNM88525X

8 Well Name and No

Burch Keely Unit #68

9 API Well No

03055
30-015-03121

10 Field and Pool, or Exploratory Area

Grbg Jackson; SR-Q-Grbg-SA

11 County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/ Resume)	<input type="checkbox"/> Water Shut-off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13 Describe Proposed or Completed Operation (clearly state all pertinent details including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of pertinent markers and sands. Attach the Bond under which the work will performed or provide the Bond No. on file with the BLM/ BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notice shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Marbob Energy Corporation proposes to plug & abandon this well.

(See attached **REVISED** procedure & wellbore schematics)SEE ATTACHED FOR
CONDITIONS OF APPROVALRECLAMATION PROCEDURE
ATTACHED14 I hereby certify that the foregoing is true and correct
Name (Printed/ Typed)

Diana J-Briggs

Title

Production Manager

Signature

Date

APPROVED
March 31, 2010

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

APR 7 2010
Date

/s/ Dustin Winkler

Conditions of approval, if any are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

BUREAU OF LAND MANAGEMENT
CARLSBAD FIELD OFFICE

Title 18 U.S.C. Section 1001 AND Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

4/12/2010

REVISED TO REFLECT BLM CONDITIONS OF APPROVAL

BKU 68
1980' fnl, 660' fel
Unit H, Sec. 23, T17S, R29E
Eddy Co., NM
LC-028784-B

RECEIVED

MAR 23 2010

Plug and Abandonment Procedure
10 Sept 09

[KBC.....]

Basic Data:

8-5/8" @ 440' 50 sx. Calc TOC 80' assuming 10" hole plus 30% excess.

7" @ 2564' 100 sx. Calc. TOC 1350' assuming 8" hole plus 30% excess.

5-1/2" liner 2516-3290' TOC 2835' TS

Note: Notify BLM inspectors in Carlsbad (575-361-2822) at least 24 hrs. before starting plugging operation.

Procedure:

1. If tubing in good shape, can use it for plugging. If in bad or questionable condition, lay tubing down and pick up a work string. Run bit and scraper to 2425'.
2. Install packoff, run gauge ring to 2425' if necessary and set CIBP + 35' cement at 2400'. Shoot 8 squeeze holes at 890' (100' below base salt at 790') and 8 squeeze holes at 540' (100' below 8-5/8" shoe).
3. RIH with tubing to approx. 2350' and circulate 100 bbls of 9 ppg brine mixed with 25 sx per 100 bbls of salt gel into well. POOH with tubing.
4. Set retainer at 840'. RIH with tubing and attempt to establish injection into perfs at 890'. If injection can be established, pump 75 sx Class "C" neat cement. Put 50 sx. below retainer, sting out and spot 25 sx on top of retainer. If injection can't be established, spot 25 sx. Class "C" cement + 2% CaCl₂ on top of retainer (14.8 ppg, 1.32 cfps, 6.3 gwps). WOC a couple of hours and tag plug on top of retainer. TOC must be 740' or shallower (should tag at approx. 700').
5. Set retainer at 490'. RIH with tubing and attempt to establish injection into perfs at 540'. If injection can be established, pump 130 sx Class "C" neat cement. Put 100 sx. below retainer, sting out and spot 30 sx on top of retainer. If injection can't be established, spot 30 sx. Class "C" cement + 2% CaCl₂ on top of retainer (14.8 ppg, 1.32 cfps, 6.3 gwps). WOC a couple of hours and tag plug on top of retainer. TOC must be 355' or shallower (should tag at approx. 320').

Note: If unable to establish injection and pump cement below retainer at 490' above, shoot 8 squeeze holes 20' above where cement was tagged on top of retainer and 8 squeeze holes at 75', RIH with packer/retainer to 100' above squeeze holes and pump 25 sx. Class "C" + 2% CaCl₂. Flush to packer/retainer and TOOH with packer/tubing. If can't inject into squeeze perfs, spot 25 sx. Class "C" + 2% CaCl₂ inside 7" casing at deepest squeeze hole depth.

6. Shoot 8 squeeze holes at 75' (if not done already). Tie onto 7", pump down 7" casing and attempt to establish circulation to surface up the 8-5/8" x 7" annulus and outside the 8-5/8". If circulation or injection can be established, pump 75 sx. Class "C" + 2% CaCl₂ (14.8 ppg, 1.32 cfps, 6.3 gwps) to fill the well from 75' to surface with cement inside the 7" and cement outside the 7" and 8-5/8" casings. Pump more cement if necessary to achieve circulation to surface (if in circulation scenario). If neither circulation nor injection could be established, fill 7" casing from 125' to surface with 25 sx. Class "C" + 2% CaCl₂.
7. Cut wellhead and casings off 3' below ground level and remove. If circulation to surface could not be established in Step 6 above and the 8-5/8" and/or 8-5/8" x 7" annuli aren't filled to surface, fill them to surface with cement before welding the plate onto the 8-5/8".
8. Weld plate onto 8-5/8" stub. Weld a 4" diameter dry hole marker onto plate such that 4' of it is above ground level. The following information needs to be placed on the marker:

Marbob Energy, BKU 68, 1980' fnl, 660' fel, Unit H, Sec. 23, T17S, R29E, LC-028784-B
Date well plugged

7. Cut off anchors, and reclaim location per BLM specs.

Kbc/bku 68 plug

Well: BKV 68

(Burch BB-8)

Location: 1980' FNL 660' FEL

H - 23-175-290

Eddy NM

30-015-03121

LC 028784-B

Zero: 3' AGL

KB: 3598'

GL: 3595'

Casing Program:

Size	Wt.	Grade	Conn.	Depth
8 5/8"	28			440'
7"	24			2564'
5 1/2"	17			2516-3270


Ø 2/43

10" hole + 30% x 8 5/8" = .182 CF/F

8" hole + 30% x 7" = .126 CF/F

8 5/8" x 7" = .10833 CF/F

7" = .1273 CF/F



Well: BKV 68

(Burch BB-8)

Location: 1980' FNL, 660' FEL

H-23-173-291

Eddy NM

30-D13-03121

LC 028784-B

Zero: 3' AGL

KB: 3598'

GL: 3595'

Casing Program:

Size	Wt.	Grade	Conn	Depth
8 7/8"	28			440'
7"	24			2564'
5 1/2"	17			2516-3270'


Ø 2/43

10" hole + 3 7/8" x 8 7/8" = .182 CF/F

8" hole + 3 1/2" x 7" = .106 CF/F

8 5/8" x 7" = .0833 CF/F

7" = .2273 CF/F



"After"
Unable to inject below
retention at 490'

Well: BKV 68
(Burch BB-8)

Location: 1980' FNL 660' FEL

H-23-173-29

Eddy NM

30-D13-03121

LC 028784-B

Zero: 3' AGL

KB: 3598'

GL: 3595'

Casing Program:

Size	Wt.	Grade	Conn.	Depth
8 5/8"	28			440'
7"	24			2564'
5 1/2"	17			2516-3270

Ø 2/43

10" hole + 30% x 8 5/8" = .182 CF/F

8" hole + 30% x 7" = .106 CF/F

8 5/8" x 7" : .10833 CF/F

7" : .1273 CF/F

TDS: 405'

BOS: 790'

TOC 80' Calc 10" hole + 30% excess

8 5/8" @ 440'
50 SX

TOC 1350' Calc 8" hole + 30% excess

2442-2474' (24) Grbg

7" @ 2564'
100 SX

2739'

(62) S. Andes

3186'

5 1/2" liner 2516-3270' 35 SX

S. Andes OH 3270-3564'

"Before"

6 1/4" TOC 2935' TS

BP 3270'

Marbob Energy Corporation
NMLC-028784B: Burch Keely Unit #68
API: 30-015-03055
Eddy County, New Mexico

RE: Plugging and Abandonment Procedure, Conditions of Approval

1. OK
2. OK
3. OK
4. Tag necessary due to base of salt – Otherwise OK (BOS)
5. Tag at 355' or shallower – Otherwise OK. If injection rate cannot be established, spot 25sx on top of retainer, WOC, tag and refer to 5a. (Casing shoe – TOS)
- 5a. If injection rate was not established on above plug, perf and squeeze 20' above the tagged depth. Plug is to be a minimum 100' and 25sx.
6. Verify that cement is to surface in all annuluses – Otherwise OK (Surface)
7. Submit subsequent report to BLM

See attached standard COA.

It is recommended that H2S monitoring and protection is available on site.

DHW 012510

BUREAU OF LAND MANAGEMENT
Carlsbad Field Office
620 East Greene Street
Carlsbad, New Mexico 88220
575-234-5972

Permanent Abandonment of Federal Wells
Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within ninety (90) days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

2. **Notification:** Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.

3. **Blowout Preventers:** A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. **Mud Requirement:** Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.

5. **Cement Requirement:** Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. In lieu of a cement plug in a cased hole, a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Any plug that requires a tag will have a minimum WOC time of 4 hours.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. **Dry Hole Marker:** All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). **The BLM is to be notified when the wellhead is cut off to verify that cement is to surface in the casing and all annuluses.** The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement. The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

7. **Subsequent Plugging Reporting:** Within 30 days after plugging work is completed, file one original and five copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**

8. **Trash:** All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office
620 E. Greene St.
Carlsbad, New Mexico 88220-6292
www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, redistribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.
-

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos
Supervisory Environmental Protection Specialist
575-234-5909, 575-361-2648 (Cell)

Cody Layton
Natural Resource Specialist
575-234-5959

Terry Gregston
Environmental Protection Specialist
575-234-5958

Trishia Bad Bear
Natural Resource Specialist
575-393-3612

Bobby Ballard
Environmental Protection Specialist
575-234-2230

Todd Suter
Surface Protection Specialist
575-234-5987

Randy Rust
Environmental Protection Specialist
575-234-5943

Doug Hoag
Civil Engineering Technician
575-234-5979

Linda Denniston
Environmental Protection Specialist
575-234-5974

Jennifer Van Curen
Environmental Protection Specialist
575-234-5905

Justin Frye
Environmental Protection Specialist
575-234-5922