

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other	5. Lease Designation and Serial No. LC-028784C
2. Name of Operator Marbob Energy Corporation	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P.O. Drawer 227, Artesia, NM, 88210 (505) 748-3303	7. If Unit or CA, Agreement Designation Burch Keely Unit
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Sec. 25 T-17-S R-29-E 660' FSL 660' FWL Unit M	8. Well Name and No. Burch Keely Unit #201
	9. API Well No. 30-015-03098
	10. Field and Pool, or Exploratory Area Grbg. Jackson SR Q Grbg. SSA
	11. County or Parish, State Eddy, NM

2. CHECK APPROPRIATE BOX(es) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION	
<input type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input checked="" type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

3. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Spot 30 sacks cement at 3223', W.O.C., Tag cement top at 2992'
- 2) Load hole with mud
- 3) Spot 65 sacks cement, plug at 2788', W.O.C., Tag cement top at 2444'
- 4) Perforate casing at base of salt 910', squeeze with 60 sacks cement, W.O.C., no tag, Re-squeeze with 60 sacks cement, W/O/C., tag cement top at 799'
- 5) Perforate casing at 480', squeeze with 60 sacks cement, W.O.C., tag cement top at 350'
- 6) Perforate casing at 60', circulate cement to surface between 7" & 8-5/8" casing, leaving 7" full with 35 sacks cement, set PA marker
- 7) Job completed 7-5-95

I hereby certify that the foregoing is true and correct

Signed [Signature] Title _____ Date 7-21-95

(This space for Federal or State office use)

Approved by (ORIG. SGD.) JOE G. LARA Title PETROLEUM ENGINEER Date 7/15/96
Conditions of approval, if any: