

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN _____ DATE _____
(Other instr. _____)
(verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 054908

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
HUDSON

9. WELL NO.

4

10. FIELD AND POOL, OR WILDCAT

Grbg, Jackson, Queen D, SP

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 17, T17S, R31E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐
2. NAME OF OPERATOR
FRANKLIN, ASTON & FAIR, c/o Boyd Operating Company3. ADDRESS OF OPERATOR
P. O. Box 1756, Roswell, New Mexico 882014. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surfaceFNL FNL
900 FSL, 330 FEL

AUG 13 1979

O.C.C.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
MEXICO, OFFICE

3721 G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up and pump 150 sx. Plug down tubing to cover open hole section from 2803' to 3500'.
2. Cut off tubing @ approximately 2560'.
3. Set retainer and squeeze with 150 sx.
4. Spot 50 sx. plug in 7" at base of salt (1115')
5. Perforate at 675' and pump 100 sx. cement, leaving 100' in 7" casing.
6. Spot 10 sx. plug at surface and erect marker.
7. Clean up location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Operator

DATE 4/13/79

(This space for Federal or State office use)

APPROVED BY

TITLE ACTING DISTRICT ENGINEER

DATE

AUG 10 1979

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side