

✓

Arnold "D" Federal #8
Procedure to Mechanically Test Casing

Contact BLM in Carlsbad prior to performing test.

1. MIRUSU. Inspect anchors prior to rigging up.
2. POH laying down rods and pump. Size and type of rods are not listed in file.
3. Remove wellhead and install BOP.
4. POH with 2 3/8" production tubing.
5. Pickup up 4 3/4" bit and TIH to 2000'. POH.
6. Pickup CIBP for 5 1/2" 14# casing and TIH to 1950' and set CIBP.
7. Circulate hole with inhibited water and close pipe rams. Test casing to 500 psi for a minimum of 15 minutes with a chart. Maximum bleedoff is 10% of maximum pressure.
8. POH laying down 2 3/8" tubing. Remove BOP and install wellhead with one joint of tubing and tubing valve. Leave well SI in temporarily abandoned status.