

DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

9. LEASE DESIGNATION AND SERIAL NO.  
LC 047633 (a)

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

L.M. Swearingen "A"

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Shugart

11. SEC. T., E., N., OR BLK. AND  
SURVEY OR AREA

Sec. 14, T-18S, R-31E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ WIW

2. NAME OF OPERATOR

Atlantic Richfield Company

3. ADDRESS OF OPERATOR

P.O. Box 1978, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

1980' FNL & 660' FEL (Unit Letter H)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3730' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

This well was converted to water injection service in the Swearingen Waterflood Project on November 6, 1965. The producing wells in the northeast half of this project have watered out and this well is no longer needed. We propose to P & A as follows:

Spot 30 sx cement in and out of 7" shoe @ 3476'.  
Shoot off and recover 7" casing from free point.  
Spot 30 sx cement in and out of 7" stub; 30 sx across 8-5/8" shoe @ 950' and 10 sx in top of well. 9#/gal salt gel mud will be used to spot all cement plugs. 8-5/8" casing will remain intact. Location will be cleared and levelled, and dry hole marker will be installed.

RECEIVED

JUN-4 1970

U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

*Al Butcher*

TITLE Dist. Drlg. Supervisor

DATE 6/3/70

(This space for Federal or State office use)

APPROVED

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED  
JUN - 4 1970  
R. L. BECKMAN  
ACTING DISTRICT ENGINEER

\*See Instructions on Reverse Side