

Operator SWR Operating Co. -  
 Well Featherstone #1  
 Unit K Section 5 Township 19 Range 31  
 API # 30-015-05744

TOPS

T. Salt 820  
 B. Salt 2160  
 Yates 2435  
 Glorieta \_\_\_\_\_  
 Delaware \_\_\_\_\_  
 Bone Sp. \_\_\_\_\_  
 Abo \_\_\_\_\_  
 Wolfcamp \_\_\_\_\_  
 Morrow \_\_\_\_\_  
 Devonian \_\_\_\_\_  
 Fusselman \_\_\_\_\_  
 Other \_\_\_\_\_

← Perf 8 5/8" & 5 1/2" @ 60' Place 60' of cmt inside & outside of both csq. strings 0' - 60'

← Place 100' of cmt inside & outside of csq. 770' - 870' - TAG

← Perf csq @ 870'

← Place 100' of cmt inside & outside of csq 2200' - 2300' - TAG

← Perf csq @ 2300'

2332 — TOC @ 50%

← 25 SX Plug @ 3200' - TAG

3228-3252 — Perfs  
 3415 — C7AD 4 1/4" cmt - 3-86  
 3446-3486 — Perfs

5 1/2" 3715'  
 363 SX  
 7 7/8" hde

- Contact OCD 24 hrs. prior to any work done
- Salt gel mud consisting of 10# brine with 25 of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.