

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. Oil Conservation District 2  
1301 W. CHURCH ST.  
Artesia, NM 87003

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expites: March 31, 1993

CIBP

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT-" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well  
Oil ☐ Gas ☐  
☒ Well ☐ Well ☐ Other ☐ (SWR Op Co)  
2. Name of Operator  
HANSON OPERATING COMPANY, INC.  
3. Address and Telephone No. P. O. Box 1515  
Roswell, New Mexico 88202-1515 505-622-7330  
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
990' FSL & 330' FEL  
Section 6-19S-31E

5. Lease Designation and Serial No.  
LC-065244-A  
6. If Indian, Allottee or Tribe Name  
7. If Unit or CA, Agreement Designation  
8. Well Name and No.  
Hodges Federal #1  
9. API Well No.  
30-015-05752  
10. Field and Pool, or Exploratory Area  
Shugart Queen  
11. County or Parish, State  
Eddy County, New Mexico

**12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION		TYPE OF ACTION	
<input checked="" type="checkbox"/>	Notice of Intent	<input checked="" type="checkbox"/>	Abandonment
<input type="checkbox"/>	Subsequent Report	<input type="checkbox"/>	Recompletion
<input type="checkbox"/>	Final Abandonment Notice	<input type="checkbox"/>	Plugging Back
		<input type="checkbox"/>	Casing Repair
		<input type="checkbox"/>	Altering Casing
		<input type="checkbox"/>	OTHER
		<input type="checkbox"/>	Change of Plans
		<input type="checkbox"/>	New Construction
		<input type="checkbox"/>	Non-Routine Fracturing
		<input type="checkbox"/>	Water Shut-Off
		<input type="checkbox"/>	Conversion to Injection
		<input type="checkbox"/>	Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plug and Abandon well in the following manner as advised by Alexis Swoboda, BLM Roswell:

1. Set CIBP at 3137' with 35' of cement on top.
2. Set 100' Plug at 2100'-2200' at the base of the Salt formation.
3. Set 100' Plug at 675'-775' at the top of Salt formation.
4. Perforate at 200' or 210' to circulate cement to surface.
5. Set 50' Surface Plug.
6. Set Dry Hole Marker. Reclaim location.

RECEIVED  
UCD - ARTESIA

14. I hereby certify that the foregoing is true and correct

Signed Carol J. Garcia Title Production Analyst Date 12/05/2001

(This space for Federal or State office use)

Approved (ORIG. SGD.) ALEXIS C. SWOBODA Title PETROLEUM ENGINEER Date DEC 06 2001  
Conditions of approval if any:

Accepted for record

Only 1-11-02

swingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements

\* See Instruction on Reverse Side