

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE  
(Other instructions on  
reverse side)

Form approved.  
Budget Bureau No. 42-R1424.  
5. LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR  
Perry R. Bass

3. ADDRESS OF OPERATOR  
P. O. Box 2760, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface  
660' FSL & 1980' FEL

RECEIVED  
DEC 2 1977  
U.S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME  
Big Eddy Unit

8. FARM OR LEASE NAME  
Big Eddy Unit

9. WELL NO.  
4

10. FIELD AND POOL, OR WILDCAT  
Lusk (Strawn)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 27, T-19-S, R-31-E

12. COUNTY OR PARISH  
Eddy County

13. STATE  
New Mexico

RECEIVED

14. PERMIT NO.  
DEC 20 1977

15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
GL. 3467'

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

O. C. O.

ARTESIA, OFFICE

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐

FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐

SHOOT OR ACIDIZE ☐ ABANDON\* ☒

REPAIR WELL ☐ CHANGE PLANS ☐

(Other) ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐

FRACTURE TREATMENT ☐ ALTERING CASING ☐

SHOOTING OR ACIDIZING ☐ ABANDONMENT\* ☐

(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Abandonment operations are expected to begin within 30 days after approval.

Procedure: (1) RU P/A unit, install manual BOPE. (2) Pull tubing and packer. (3) RIH tubing open-end and set cement plug at 11,400'-11,175' with 50 sx. Class "H" cement. WOC hours. (4) Displace hole with 9.6 ppg. Brine gel mud. POOH laying down tubing. (5) ND PE to PU 4 1/2" casing and remove slips. Weld on 4 1/2" casing extension and install BOPE 8 5/8" casing. (6) RIH with free point tool to find 4 1/2" casing free point. Test casing 1,000 psi. (7) RIH with jet charge. Cut 4 1/2" casing at estimated free point depth of 8,000'. (8) PU 4 1/2" casing. (9) Set cement plug at estimated 4 1/2" casing cut off point 8,000'-7,775' with 75 sx. Class "H" cement. (10) Pull casing to 6,900' and set cement plug from 6,900'-6,675' with 75 sx. Class "H" cement. (11) Pull casing to 5,400' and set cement plug from 5,400'-5,175' with 75 sx. Class "H" cement. (12) Pull casing to 4,060' and set cement plug from 4,060'-3,910' with 50 sx. Class "H" cement. (13) Pull casing to 750' and set cement plug from 750'-600' with 50 sx. Class "H" cement. (14) Pull casing to 20' and set cement plug from 20'-surface with 15 sx. Class "H" cement. (15) Pull casing to surface and lay down. (16) RD P/A unit and manual BOPE. (17) Install 4" OD P/A marker 4 feet above mean ground vel. (18) Clean location for final inspection.

Note: All intervals between cement plugs will be mud filled.

18. I hereby certify that the foregoing is true and correct

SIGNED Jane Young

TITLE Engineer Assistant

DATE 12-1-77

(This space for Federal or State office use)

APPROVED BY Joe J. Lane

TITLE ACTING DISTRICT ENGINEER

DATE DEC 19 1977

CONDITIONS OF APPROVAL, IF ANY: