

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

RECEIVED

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

MAY - 8 1980

1. <input checked="" type="checkbox"/> OIL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <u>P&A Well</u>		5. LEASE DESIGNATION AND SERIAL NO. <u>N.A.</u>	
2. NAME OF OPERATOR <u>Southland Royalty Company V S Welch</u>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR <u>1100 Wall Towers West, Midland, Texas 79701</u>		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface <u>1650' FNL, 2310' FEL, Sec. 27, T-18-S, R-31-E</u>		8. FARM OR LEASE NAME <u>V. S. Welch Hinkle</u>	
14. PERMIT NO.		9. WELL NO. <u>27</u>	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) <u>N.A.</u>		10. FIELD AND POOL, OR WILDCAT <u>Shugart</u>	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>25-18-31</u> <u>27-</u>	
		12. COUNTY OR PARISH <u>Eddy</u>	
		13. STATE <u>N.M.</u>	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) Re-enter & re-plugPULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up and drill out plugs at surface, @ 8 5/8" csg shoe and 1910' (See attached schematic).
2. Tag plug @ 3880'. Spot 100' plug from 3780-3880'.
3. Spot 100' plug from 3400-3500' to isolate Penrose.
4. Spot 200' plug @ base of salt 2250-2450' (tag plug).
5. Spot 100' plug across 8 5/8" csg shoe @ 890'.
6. Spot 100' plug across 8 5/8" csg stub @ 724'.
7. Spot 20 sx. plug @ surface.

18. I hereby certify that the foregoing is true and correct

SIGNED C. Harvey CanTITLE District EngineerDATE 2-7-80

(This space for Federal or State office use)

(Sgt. Sgd.) GEORGE H. STEWARTTITLE ASSISTANT DISTRICT ENGINEERAPPROVED BY
CONDITIONS OF APPROVAL, IF ANY:DATE MAY 27 1980