

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B - 8096

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
Anadarko Petroleum Corporation

3. Address of Operator
P.O. Drawer 130, Artesia, New Mexico 88211-0130

4. Well Location
Unit Letter I : 990 Feet From The East Line and 1650 Feet From The South Line
Section 9 Township 19S Range 29E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3372' GL

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RUPU. GIH w/tbg. Circ hole with salt gel mud.
2. Set 4½ CIBP on tbg @ 2110' to shut off Queen perfs.
3. Spot 50' Class C cement on top of CIBP. This plug covers Queen top.
4. Spot 25sx Class C cement from 1700' up to 1330'. This plug covers 7-Rivers top.
5. Perforate 4 squeeze holes @ 1000' (100' below salt). GIH w/pkr & cement squeeze w/25 sx Class C w/3% CaCl, leaving 100' cement in csg. This plug covers base of salt.
6. Tag top of plug w/perf gun after set time. Pull up & perf 4 squeeze holes @ 250' (50' above top of salt). Tie onto 4½" csg & establish circulation down 4½" out squeeze holes & up 8-5/8" surface. Circ cement. This plug covers top of salt and surface plug.

NOTE: If cannot establish circulation, will cement squeeze with 25 sx & tag top of plug. Then set surface plug.

7. Cut off all csg & anchors below surface. Set P&A marker; clean and level location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Mike Braswell TITLE Field Foreman DATE 11-12-92
(505)
TYPE OR PRINT NAME Mike Braswell TELEPHONE NO. 677-2411

(This space for State Use)

APPROVED BY Mark Braswell TITLE Field Foreman DATE NOV 25 1992

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

APPROVAL VALID FOR 30 DAYS
PERMIT EXPIRES NOV 25 1992
ALL DRILLING UNDERWAY

93-1001

1001-1002

1001-1003
1001-1004



Cont. State #7

